

S&W 52 VORTEX VIPER/VENOM SIGHT MOUNT - EGW S&W 52 VORTEX VIPER/VENOM SIGHT MOUNT

[Optics & Mounting](#) > [Rings, Mounts & Bases](#) > [Handgun Bases](#)

EGW's red dot sights are meant to be installed from the left to the right (with the muzzle facing forward). The dovetail has a progressive taper to allow for easier install. Simply remove the rear sight on your gun and replace it with mount in order to mount your Vortex Viper/Venom, Burris FastFire, or Docter red-dot sight. You can take the mount off and replace your rear sight at any time. Mounting hardware included. Installation Instructions Remove the rear sight* Install the EGW Sight Mount in the dovetail Tighten set screw (if applicable) Place the red dot sight on the EGW Sight Mount (placing a small piece of paper between the red dot sight and the sight mount will make for easier removal and will keep Loctite off of the red dot sight.) Apply blue Loctite to the provided mounting screws Torque mounting screws to 15in/lbs 2 Button Head Cap Screws - Provided for Vortex Viper and Venom Sights 2 Flat Head Cap Screws - Provided for Burris FastFire and Docter Sights The screws that are included with this mount require a 5/64" allen wrench for installation. Modification of your firearm may nullify the manufacturer's warranty. This product should be installed and checked by a qualified gunsmith. No liability is expressed or implied for damage or injury which may result from improper installation or use of this product. This mount fits: Smith & Wesson Model 52 This mount does not fit: Smith & Wesson Model 41



Attributes

- Name: [EGW S&W 52 VORTEX VIPER/VENOM SIGHT MOUNT](#)
- Manufacturer: [EGW](#)
- Product no.: 296000799
- Mfr. No.: 49309
- Colour: Black
- Material: Aluminum
- Model: 52
- Number of Bases: 1-Piece
- Style: Tactical
- Weapon type: Smith & Wesson
- Delivery weight: 0.045kg
- Shipping height: 25mm
- Shipping width: 76mm
- Shipping length: 140mm
- UPC: 841370113637

Item details

Made in USA

Table of Contents

- Startpage
- S&W 52 VORTEX VIPER/VENOM SIGHT MOUNT Safety Instruction Guide
- About Us

S&W 52 VORTEX VIPER/VENOM SIGHT MOUNT Safety Instruction Guide

Introduction

Thank you for choosing the S&W 52 Vortex Viper/Venom Sight Mount by EGW. This guide provides essential safety instructions and guidelines to ensure safe installation and use of the product. Please read this document carefully before proceeding.

General Safety Guidelines

- Ensure that your firearm is unloaded before beginning the installation process.
- Always handle firearms with care and follow basic firearm safety rules.
- This product is designed for use with Smith & Wesson Model 52. It is not compatible with Smith & Wesson Model 41.
- Modification of your firearm may void the manufacturer's warranty. Consult a qualified gunsmith for assistance if needed.
- Report any unsafe products or accidents to the appropriate authorities.
- Regularly check for any recall updates on the EU Safety Gate platform.

Specific Safety Precautions for Use

- Ensure that the mounting area is clean and free from debris before installation.
- Use only the recommended tools for installation to avoid damage to the mount or firearm.
- Always apply blue Loctite to the provided mounting screws to prevent loosening during use.
- Be cautious when handling tools and screws to avoid injury.
- Do not attempt to install or remove the sight mount while the firearm is loaded.
- Keep the sight mount and tools out of reach of children and vulnerable individuals.

Instructions for Installation and Usage

1. Remove the Rear Sight

- Ensure the firearm is unloaded.
- Carefully remove the rear sight from your Smith & Wesson Model 52.

2. Install the EGW Sight Mount

- Place the EGW Sight Mount in the dovetail from left to right, with the muzzle facing forward.
- Tighten the set screw (if applicable) to secure the mount in place.

3. Attach the Red Dot Sight

- Place your Vortex Viper/Venom, Burris FastFire, or Docter red dot sight on the EGW Sight Mount.
- For easier removal, place a small piece of paper between the red dot sight and the mount to keep Loctite off the sight.

4. Apply Loctite

- Apply blue Loctite to the provided mounting screws before installation.

5. Torque Mounting Screws

- Use a 5/64" allen wrench to tighten the mounting screws to a torque of 15 in/lbs.

- Ensure that both the 2 Button Head Cap Screws (for Vortex Viper and Venom Sights) and 2 Flat Head Cap Screws (for Burris FastFire and Docter Sights) are properly secured.

6. Final Check

- Doublecheck all screws and components to ensure everything is securely fastened.

Disposal Instructions

- Dispose of any packaging materials in accordance with local regulations.
- If the product is damaged or no longer in use, follow local guidelines for the disposal of metal and electronic components.

Contact Information for Further Support

For product support or safety inquiries, please refer to the manufacturer's website or customer service resources.

This guide is designed to keep you and others safe while using the S&W 52 Vortex Viper/Venom Sight Mount. Always prioritize safety and consult a professional if you have any doubts or questions regarding installation and use.

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk