

# AR-15 EARLY 3 PRONG FLASH HIDER 22 CAL - BROWNELLS EARLY 3 PRONG 22 CALIBER FLASH HIDER, 1/2"-28, STEEL, BLACK

[Rifle Parts](#) > [Muzzle Devices](#) > [Flash Hiders](#)

## Complete your Retro build with the Brownells Improved 3 Prong Flash Hider

Complete your Retro build with the Brownells Early 3 Prong "Duckbill" flash hider. The "Duckbill" flash hider was found on some of the earliest AR-15 rifles such as the Colt Model 601 used by the US Air Force. These were eventually phased out due to the lightweight prongs bending. Looks great at home on a Retro rifle, or any AR-15 of your choice. Original, Early 3 Prong "Duckbill" design Phosphate finish 1/2-28 threads Modeled directly off of original part Build the proper 601 or Retro rifle of your choice with an Early 3 Prong Flash Hider. This muzzle device does not have wrench flats to install. A strap wrench or 3 prong armorers wrench is needed to properly install.



Complete your Retro build with the Brownells Early 3 Prong "Duckbill" flash hider. The "Duckbill" flash hider was found on some of the earliest AR-15 rifles such as the Colt Model 601 used by the US Air Force. These were eventually phased out due to the lightweight prongs bending. Looks great at home on a Retro rifle, or any AR-15 of your choice. Original, Early 3 Prong "Duckbill" design Phosphate finish 1/2-28 threads Modeled directly off of original part Build the proper 601 or Retro rifle of your choice with an Early 3 Prong Flash Hider. This muzzle device does not have wrench flats to install. A strap wrench or 3 prong armorers wrench is needed to properly install.

## Attributes

- Name: [BROWNELLS EARLY 3 PRONG 22 CALIBER FLASH HIDER, 1/2"-28, STEEL, BLACK](#)
- Manufacturer: [BROWNELLS](#)
- Product no.: 078000391
- Mfr. No.: II008
- Caliber: 22 Caliber (.223-.224)
- Finish: Black
- Material: Steel
- Threads: 1/2-28
- Weapon type: AR-15
- Delivery weight: 0.068kg
- Shipping height: 94mm
- Shipping width: 89mm
- Shipping length: 13mm
- UPC: 050806003736

## Item details

Made in USA

# Table of Contents

- [Startpage](#)
- [Safety Instruction Guide for AR15 Early 3 Prong Flash Hider](#)
- [About Us](#)

# Safety Instruction Guide for AR15 Early 3 Prong Flash Hider

## Introduction

Thank you for choosing the AR15 Early 3 Prong Flash Hider. This product is designed to enhance your Retro build while ensuring safety during use. This guide provides essential safety instructions, installation guidelines, and disposal information to help you use this product safely and effectively.

## General Safety Guidelines

- Ensure the product is used only for its intended purpose.
- Always handle firearms and firearm accessories with care.
- Keep the flash hider out of reach of children and unauthorized users.
- Regularly inspect the flash hider for any signs of damage or wear.
- Report any unsafe conditions or incidents to the appropriate authorities.
- Stay informed about product recalls through the EU Safety Gate platform.

## Specific Safety Precautions for Use

- Only use the flash hider on compatible firearms (AR15, .22 caliber).
- Avoid using excessive force during installation or removal to prevent damage.
- Do not modify the flash hider in any way, as this can compromise safety and functionality.
- Wear appropriate safety gear, including eye protection, when handling firearms.
- Always ensure the firearm is unloaded before installation or maintenance of the flash hider.
- Follow all local laws and regulations regarding firearm accessories.

## Instructions for Installation and Usage

### Installation Instructions

1. **Prepare the Firearm:** Ensure the AR15 is unloaded and pointed in a safe direction.
2. **Select the Tool:** Obtain a strap wrench or a 3 prong armorers wrench for installation.
3. **Align the Flash Hider:** Position the flash hider over the muzzle of the firearm, ensuring the threads are aligned.
4. **Secure the Flash Hider:**
  - Use the strap wrench or armorers wrench to tighten the flash hider onto the muzzle.
  - Do not overtighten, as this may damage the threads or the flash hider.
5. **Final Check:** Ensure the flash hider is securely attached and does not wobble.

### Usage Instructions

- Always check that the flash hider is properly installed before firing.
- Be aware of your surroundings and ensure a safe shooting environment.
- Regularly clean the flash hider according to the manufacturer's recommendations to maintain performance.

## Disposal Instructions

- Dispose of the flash hider in accordance with local regulations regarding metal and firearm accessories.
- Do not dispose of the flash hider in regular household waste.
- If the flash hider is damaged or no longer usable, consult local authorities for proper disposal methods.

## **Contact Information for Further Support**

For safety inquiries or additional support, please refer to the contact information provided with your product packaging or visit the manufacturer's website.

By following these guidelines, you can ensure safe and effective use of the AR15 Early 3 Prong Flash Hider. Your safety and the safety of others is paramount. Thank you for your attention to these important instructions.

# About Us

## Brownells UK

### **Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories**

Unit 1, Laughing Dog Industrial Estate  
London Road  
Rugby  
Warwickshire  
CV23 9LP

[www.brownells.co.uk](http://www.brownells.co.uk)