

RUGER® MK I™/MK II™ ALLEN HEAD GRIP SCREWS - GRIP SCREWS FOR RUGER MK I/II NICKEL 4 PACK

[Handgun Parts](#) > [Grip Parts](#) > [Grip Screws](#)

Improved Looks & Function

These excellent looking Allen-head screws will dress up any Ruger® Mk I™ or Mk II™ pistol plus give positive wrench engagement to help prevent stripped-out grip screws. Same diameter head as the standard screw, fits flush on all factory and aftermarket grips.



Attributes

- Name: [GRIP SCREWS FOR RUGER MK I/II NICKEL 4 PACK](#)
- Manufacturer: [BROWNELLS](#)
- Product no.: 080000055
- Mfr. No.:
- Make: Ruger
- Model: Mark I,Mark II
- Quantity: 4
- Delivery weight: 0.005kg
- Shipping width: 83mm
- Shipping length: 146mm
- UPC: 050806005129

Item details

Made in USA

Table of Contents

- Startpage
- RUGER® MK I™ /MK II™ ALLEN HEAD GRIP SCREWS SAFETY INSTRUCTIONS
- About Us

RUGER® MK I™/MK II™ ALLEN HEAD GRIP SCREWS SAFETY INSTRUCTIONS

Introduction

Thank you for choosing the RUGER® MK I™/MK II™ Allen Head Grip Screws. These screws are designed to enhance the appearance and functionality of your Ruger® Mk I™ or Mk II™ pistol. This safety instruction guide provides essential information to ensure the safe use, installation, and disposal of the product in compliance with the EU General Product Safety Regulation (GPSR).

General Safety Guidelines

- Ensure that the product is used only for its intended purpose.
- Regularly inspect the screws for any signs of wear or damage before installation.
- Keep the product out of reach of children and vulnerable individuals.
- Report any unsafe products or accidents to local authorities.
- Stay informed about recall updates via the EU's Safety Gate platform.

Specific Safety Precautions for Use

- Always use the appropriate tools to install or remove the screws to avoid injury or damage.
- Do not overtighten the screws, as this may strip the threads or damage the grip.
- Ensure that the screws are compatible with your specific Ruger® Mk I™ or Mk II™ model.
- Avoid using the screws in any application other than specified by the manufacturer.

Instructions for Installation and Usage

1. Preparation:

- Gather necessary tools: a 3/32" Allen wrench and a clean cloth.
- Ensure that the pistol is unloaded and pointed in a safe direction.

2. Installation:

- Remove the existing grip screws using the Allen wrench.
- Clean the screw holes to remove any debris or old threadlocker.
- Take one of the new Allen head grip screws and insert it into the corresponding hole.
- Use the Allen wrench to tighten the screw gently until it is snug. Do not overtighten.
- Repeat the process for all screws.

3. PostInstallation:

- Check that all screws are securely fastened.
- Inspect the grip for proper alignment and fit.
- Store any unused screws in a safe location.

Disposal Instructions

- Dispose of any used or damaged screws responsibly, following local regulations for metal waste.
- Do not dispose of the screws in regular household waste.
- Consider recycling options available in your area.

Contact Information for Further Support

For any questions or concerns regarding the RUGER® MK I™ /MK II™ Allen Head Grip Screws, please refer to the manufacturer's contact channels. Always ensure that you have the product details at hand when seeking assistance.

Thank you for prioritizing safety and compliance while enjoying your Ruger® pistol.

About Us

Brownells Austria

Brownells - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

www.brownells.at