

REPLACEMENT STAKER HEAD - BROWNELLS REPLACEMENT STAKER HEAD

[Gunsmith Tools](#) > [Handgun Tools](#) > [Grip Tools](#)

REPLACEMENT STAKER HEAD



Attributes

- Name: [BROWNELLS REPLACEMENT STAKER HEAD](#)
- Manufacturer: [BROWNELLS](#)
- Product no.: 080644001
- Mfr. No.:
- Weapon type: Universal Handguns
- Delivery weight: 0.005kg
- Shipping width: 83mm
- Shipping length: 146mm
- UPC: 050806019959

Item details

Made in USA

Table of Contents

- [Startpage](#)
- [Replacement Staker Head Safety Instruction Guide](#)
- [About Us](#)

Replacement Staker Head Safety Instruction Guide

Introduction

Thank you for choosing the Replacement Staker Head by Brownells. This guide provides important safety information and instructions for the proper use and disposal of this product. Please read this guide carefully to ensure safe and effective use.

General Safety Guidelines

- Always inspect the Replacement Staker Head before use for any signs of damage or wear.
- Use the product only as intended and according to the instructions provided in this guide.
- Keep the Replacement Staker Head out of reach of children and vulnerable individuals.
- Report any unsafe products or accidents to the appropriate authorities.
- Check for recall updates on the EU's Safety Gate platform to ensure the product is safe for use.

Specific Safety Precautions for Use

- Ensure that the Replacement Staker Head is compatible with your universal handgun before installation.
- Avoid using the product if it appears damaged or malfunctioning.
- Do not modify the Replacement Staker Head in any way, as this may compromise its safety and effectiveness.
- Wear appropriate protective gear, such as safety glasses, when using the Replacement Staker Head to prevent injury.
- Always follow the manufacturer's guidelines for usage to prevent accidents.

Instructions for Installation and Usage

1. Preparation

- Ensure your workspace is clean and free from any obstructions.
- Gather all necessary tools for installation.

2. Installation

- Carefully remove the Replacement Staker Head from its packaging.
- Align the Replacement Staker Head with the designated area on your universal handgun.
- Securely attach the Replacement Staker Head according to the manufacturer's instructions.
- Doublecheck that the head is firmly in place before use.

3. Usage

- Use the Replacement Staker Head as per the intended function.
- Do not exceed the recommended usage limits to avoid damage to the product or injury to yourself.
- Regularly check the Replacement Staker Head during use for any signs of wear or damage.

Disposal Instructions

- Dispose of the Replacement Staker Head in accordance with local regulations for nonhazardous materials.
- Do not dispose of the product in regular household waste if it contains any hazardous components.
- Consider recycling options available in your area for responsible disposal.

Contact Information for Further Support

For additional support or inquiries regarding the Replacement Staker Head, please refer to the manufacturer's website or contact their customer service. Ensure you have the product details and any relevant information ready when seeking assistance.

Thank you for your attention to these safety instructions. Your safety and satisfaction are our top priorities. Enjoy using your Replacement Staker Head responsibly!

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk