

12" HAVOC 37MM FLARE LAUNCHER - SPIKES TACTICAL KAOS STOCK SYSTEM FOR 12" HAVOC 37MM FLARE LAUNCHER BLACK

[Home](#)

SPIKE'S TACTICAL 12" HAVOC 37MM FLARE LAUNCHER Breech-loading 37mm flare launcher clamps securely to the bottom rail of any 7"" or longer Picatinny handguard. Lets you use 5^{3/4}"" U.S. Coast Guard approved flare, smoke, or gas rounds for field operations or training. A single push of the button quickly opens the launcher to remove a spent round and insert a fresh cartridge. STZ pushbutton cylindrical breech lock is far stronger than lever locks typically used on this type of launcher. 12" Launcher tube slides forward for rear feed. Mounting hardware and instructions included. Kaos Stock Systems allow you to take your existing rail mounted Havoc Launcher and turn it into a stand-alone weapon system. It is compatible with most aftermarket AR-15 stocks, latch plates & pistol grips. Kaos Stock System features a ST M4 Stock as well as Mil-Spec A2 pistol grip, 1913 Picatinny Top Rail, Buffer Tube, Latch Plate, and Castle Nut. SPECS Construction: 6061 T6 aluminum Finish: Hardcoat anodized, and 1018 cold-rolled steel, oxide coated, black. Length: 12" Launcher: 12-5/8" (32cm) OAL, 5" (22.8cm) tube length. Weight: 2 lb., 14 oz. (1.4kg) Side-Swivel Breach Loading Design Push-button Breach Lock One-piece Tube & Grip Supports 5 3/4" USCG Munitions Compatible with 7" and longer rail systems



Attributes

- Name: [SPIKES TACTICAL KAOS STOCK SYSTEM FOR 12" HAVOC 37MM FLARE LAUNCHER BLACK](#)
- Manufacturer: [SPIKES TACTICAL](#)
- Product no.: 100011261
- Mfr. No.: STH1200
- Finish: Black Oxide
- Style: Clamp
- Delivery weight: 1.021kg
- Shipping height: 46mm
- Shipping width: 178mm
- Shipping length: 594mm
- UPC: 815648022075

Item details

Made in USA

Table of Contents

- Startpage
- Safety Instruction Guide for 37MM Flare Launchers & Kaos Stock Systems
- About Us

Safety Instruction Guide for 37MM Flare Launchers & Kaos Stock Systems

Introduction

Thank you for choosing the 37MM Flare Launchers & Kaos Stock Systems by Spikes Tactical. This guide provides essential safety instructions and usage guidelines to ensure your safe and effective operation of the product. Please read this manual carefully before use.

General Safety Guidelines

- Ensure that you are of legal age and possess the necessary permits to use flare launchers in your region.
- Always treat the flare launcher as if it is loaded, even when not in use.
- Keep the flare launcher out of reach of children and unauthorized users.
- Use only approved 5 3/4" U.S. Coast Guard flares, smoke, or gas rounds.
- Inspect the launcher before each use for any signs of damage or wear.
- Avoid pointing the launcher at yourself or others during use.
- Do not modify the flare launcher or use it for any purpose other than intended.
- Always wear appropriate safety gear, including eye protection, when operating the flare launcher.
- Be aware of your surroundings and ensure a safe area for firing flares.
- Follow all local laws and regulations regarding the use of flare launchers.

Specific Safety Precautions for Use

• Loading and Unloading:

- Ensure the launcher is pointed in a safe direction before loading or unloading.
- Always use the pushbutton mechanism to open the breech lock; do not force it open.
- Do not attempt to load the launcher with a round if the breech lock is not fully closed.

• Firing:

- Only fire the launcher when you are in a safe and open area.
- Keep your hands and face clear of the launcher's muzzle when firing.
- Do not attempt to fire the launcher if it is obstructed or if you suspect a malfunction.

• PostUse:

- After use, ensure the launcher is completely unloaded.
- Store the flare launcher in a secure and dry location.

Instructions for Installation and Usage

Installation

1. Mounting the Launcher:

- Select a suitable Picatinny handguard that is at least 7" long.
- Align the launcher with the bottom rail of the handguard.
- Use the included mounting hardware to secure the launcher firmly in place.
- Ensure that the launcher is stable and does not move when pulled or pushed.

2. Attaching the Kaos Stock System:

- Remove the existing railmounted Havoc Launcher from the handguard if applicable.
- Follow the instructions provided with the Kaos Stock System for proper attachment to your launcher.
- Ensure all components (ST M4 Stock, MilSpec A2 pistol grip, and others) are securely attached.

Usage

1. Loading the Launcher:

- Ensure the launcher is pointed in a safe direction.
- Press the pushbutton to open the breech lock.
- Insert a fresh cartridge into the breech.
- Close the breech lock securely.

2. Firing the Launcher:

- Stand in a stable position with a clear line of sight to the target.
- Aim the launcher at the desired target area.
- Pull the trigger to fire the flare.

3. Unloading the Launcher:

- After firing, press the pushbutton to open the breech lock.
- Remove the spent cartridge and dispose of it according to local regulations.
- Insert a new cartridge if you intend to fire again.

Disposal Instructions

- Dispose of spent cartridges and any damaged flares in accordance with local hazardous waste disposal regulations.
- Do not dispose of the flare launcher in regular household waste.
- Contact your local waste management authority for guidance on proper disposal methods.

Contact Information for Further Support

For safety inquiries or assistance regarding this product, please refer to the contact information included with your purchase or visit the manufacturer's website.

By following these guidelines, you can ensure a safe and enjoyable experience with your 37MM Flare Launchers & Kaos Stock Systems. Always prioritize safety and adhere to local regulations regarding the use of flare launchers. Thank you for your attention to these important safety instructions.

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk