

# PROFESSIONAL RETICLE LEVELING SYSTEM

[Gunsmith Tools & Supplies](#) > [Sight & Scope Installation Tools](#) > [Scope Reticle Levelers](#)

Professional Reticle Leveling System: The Wheeler Professional Reticle Leveling System is a precision tool and technique designed to allow a scope to be perfectly leveled on any firearm with ease. CNC machining, factory adjusted calibration set screws, anodized aluminum construction and protective molded case put this instrument in a class of its own. The system is comprised of two machined aluminum level housings calibrated to their integrated levels. The Barrel Clamp Level is attached to the gun's barrel while the smaller Reference Level is placed on scope base, bottom half of a ring or other flat surface perpendicular to the vertical axis of the gun. The gun is then rotated until the Reference Level is aligned. The tuning adjustment knob on the Barrel Clamp Level is then turned until its level is centered to match the Reference Level. At this point the Barrel Clamp Level is calibrated to the gun's axis. The Scope can be installed loosely and the Reference Level placed on top of the scope's turret cap. The scope is rotated until the Reference Level is aligned with the Barrel Clamp Level and then simply secured in place. The Wheeler PRLS is the most effective instrument available for precision scope alignment.



## Attributes

- Name: [PROFESSIONAL RETICLE LEVELING SYSTEM](#)
- Manufacturer: [WHEELER ENGINEERING](#)
- Product no.: 100012251
- Mfr. No.: 119050
- Delivery weight: 0.329kg
- Shipping height: 159mm
- Shipping width: 152mm
- Shipping length: 267mm
- UPC: 661120190509

# Table of Contents

- Startpage
- Professional Reticle Leveling System Safety Instructions
- About Us

# Professional Reticle Leveling System Safety Instructions

## Introduction

Thank you for choosing the Wheeler Professional Reticle Leveling System (PRLS). This precision tool is designed to help you level your scope accurately on any firearm. To ensure safe and effective use of this product, please read and follow these safety instructions carefully.

## General Safety Guidelines

- Ensure that the product is used only for its intended purpose.
- Always handle firearms safely and responsibly.
- Keep the leveling system and all tools out of reach of children and unauthorized users.
- Inspect the leveling system before each use for any signs of damage or wear.
- If you encounter any issues or have concerns about the product, stop using it immediately and seek professional assistance.
- Report any unsafe products or accidents to the appropriate authorities.
- Stay informed about product recalls and safety updates via the EU's Safety Gate platform.

## Specific Safety Precautions for Use

- Always ensure that the firearm is unloaded before attaching or using the leveling system.
- Wear appropriate safety gear, such as eye protection, when working with firearms.
- Do not use the leveling system in wet or damp conditions to avoid slipping.
- Ensure that the Barrel Clamp Level is securely attached to the firearm's barrel before making any adjustments.
- Avoid placing excessive force on the leveling system during use to prevent damage.
- Be cautious of sharp edges on the aluminum components of the leveling system.

## Instructions for Installation and Usage

### 1. Preparation:

- Ensure the firearm is unloaded and pointed in a safe direction.
- Gather all necessary tools, including the Wheeler Professional Reticle Leveling System.

### 2. Attaching the Barrel Clamp Level:

- Select an appropriate location on the firearm's barrel for the Barrel Clamp Level.
- Securely attach the Barrel Clamp Level to the barrel, ensuring it is tight but not overly forceful.

### 3. Positioning the Reference Level:

- Place the smaller Reference Level on the scope base, the bottom half of a ring, or any flat surface that is perpendicular to the vertical axis of the firearm.
- Ensure the Reference Level is stable and secure.

### 4. Aligning the Levels:

- Rotate the firearm until the Reference Level is aligned correctly.
- Adjust the tuning knob on the Barrel Clamp Level until its level is centered to match the Reference Level.

## 5. Installing the Scope:

- Install the scope loosely onto the scope rings.
- Place the Reference Level on top of the scope's turret cap.
- Rotate the scope until the Reference Level aligns with the Barrel Clamp Level.

## 6. Securing the Scope:

- Once aligned, securely fasten the scope in place according to the manufacturer's instructions.

## 7. Final Checks:

- Doublecheck the alignment of both levels before taking the firearm to the range.
- Make any necessary adjustments to ensure precision.

## Disposal Instructions

- Dispose of the leveling system in accordance with local regulations and guidelines for electronic and aluminum waste.
- Do not dispose of the product in regular household waste.
- Check with local waste management facilities for proper disposal methods.

## Contact Information for Further Support

For any questions or concerns regarding the Wheeler Professional Reticle Leveling System, please refer to the product packaging for contact details for customer support. Always ensure you have the latest information regarding product safety and usage from the manufacturer.

By following these safety instructions, you can ensure a safe and effective experience with your Wheeler Professional Reticle Leveling System. Always prioritize safety when handling firearms and related equipment.

# About Us

## **Brownells Česká republika**

**Brownells - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories**

[www.brownells.cz](http://www.brownells.cz)