

# AR-15 MICRO GAS BLOCKS STEEL SET SCREW - SLR RIFLEWORKS MICRO GAS BLOCK .750 SET SCREW STEEL

[Rifle Parts](#) > [Gas System Parts](#) > [Gas Blocks](#)

## Versatility in a Low-Profile Design

AR-15 MICRO GAS BLOCKS STEEL SET SCREW Sick of that front-sight gas block? Change it out and add more versatility to your AR-15 with the addition of the SLR Rifleworks Micro Gas Block. The SLR Rifleworks Micro Gas Block is made with a low-profile design that allows clearance for most aftermarket handguards offered for the AR-15 platform, giving owners a wide range of versatility and customization options for their rifle. FEATURES Machined from 4140 billet steel Treated with QPQ melonite finish Available in .875 and .936 sizes The SLR Rifleworks Micro Gas Block also comes equipped with 0.400-inch spaced set screws to ensure your gas block never moves from its position.



Sick of that front-sight gas block? Change it out and add more versatility to your AR-15 with the addition of the SLR Rifleworks Micro Gas Block. The SLR Rifleworks Micro Gas Block is made with a low-profile design that allows clearance for most aftermarket handguards offered for the AR-15 platform, giving owners a wide range of versatility and customization options for their rifle. Machined from 4140 billet steel Treated with QPQ melonite finish Available in .625, .750, .875 and .936 sizes The SLR Rifleworks Micro Gas Block also comes equipped with 0.400-inch spaced set screws to ensure your gas block never moves from its position.

## Attributes

- Name: [SLR RIFLEWORKS MICRO GAS BLOCK .750 SET SCREW STEEL](#)
- Manufacturer: [SLR RIFLEWORKS](#)
- Product no.: 100025356
- Mfr. No.: GB7-S
- Inside Diameter: .750
- Material: Steel
- Style: Low Profile
- Weapon type: AR-15
- Delivery weight: 0.068kg
- Shipping height: 25mm
- Shipping width: 76mm
- Shipping length: 140mm

## Item details

Made in USA

US export classification: 0A501.x

# Table of Contents

- Startpage
- Safety Instruction Guide for AR15 Micro Gas Blocks
- About Us

# Safety Instruction Guide for AR15 Micro Gas Blocks

## Introduction

Thank you for choosing the SLR Rifleworks Micro Gas Block for your AR15. This guide provides essential safety instructions to ensure the safe and effective use of this product. Please read the following information carefully before installation and usage.

## General Safety Guidelines

- Always handle firearms with care and follow all safety protocols.
- Ensure the firearm is unloaded before performing any installation or maintenance.
- Use personal protective equipment (PPE) such as safety glasses and gloves during installation.
- Be aware of your surroundings and ensure that you are in a safe environment when working with firearms.
- Keep the product out of reach of children and unauthorized users.
- Regularly check for any wear or damage to the gas block and surrounding components.

## Specific Safety Precautions for Use

- Ensure that the Micro Gas Block is compatible with your AR15 model before installation.
- Do not exceed the recommended torque specifications when securing the gas block to avoid damage.
- Verify that the set screws are tightened properly to prevent movement during operation.
- If you notice any unusual performance or sounds while using your firearm, stop using it immediately and inspect the gas block.
- Always perform a function check of your firearm after installation to ensure proper operation.

## Instructions for Installation and Usage

### 1. Preparation

- Gather all necessary tools, including a torque wrench, Allen wrench, and any other required tools for installation.
- Ensure the firearm is unloaded and in a safe position.

### 2. Installation Steps

- Remove the existing gas block from your AR15 by loosening and removing the set screws.
- Clean the barrel area where the new gas block will be installed to ensure a proper fit.
- Position the SLR Rifleworks Micro Gas Block over the gas port on the barrel.
- Align the gas block with the handguard to ensure a lowprofile fit.
- Insert and handtighten the set screws into the gas block.
- Using a torque wrench, tighten the set screws to the manufacturer's recommended torque specifications.
- Doublecheck the alignment and ensure the gas block is secure.

### 3. Usage Instructions

- After installation, conduct a function check of your firearm.
- Ensure that all components are functioning correctly before taking the firearm to the range.
- Regularly inspect the gas block and surrounding areas for any signs of wear or damage.

## **Disposal Instructions**

- Dispose of any packaging materials responsibly by recycling where possible.
- If the gas block becomes damaged beyond repair, follow local regulations for disposal of metal components.
- Do not discard the product in regular household waste.

## **Contact Information for Further Support**

For any inquiries regarding the safety or performance of your SLR Rifleworks Micro Gas Block, please consult the manufacturer's website or reach out to the designated contact point for assistance.

Thank you for your attention to these safety instructions. Your safety is our priority, and we appreciate your commitment to responsible firearm ownership.

# About Us

## Brownells UK

### **Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories**

Unit 1, Laughing Dog Industrial Estate  
London Road  
Rugby  
Warwickshire  
CV23 9LP

[www.brownells.co.uk](http://www.brownells.co.uk)