

SNAP CAPS BLUE VALUE PACKS - A-ZOOM 450 BUSHMASTER SNAP CAP BLUE 2PK

[Gunsmith Tools](#) > [General Gunsmith Tools](#) > [Cartridge Dummies](#)

A-Zoom Snap Caps Blue Value Packs are perfect for safety training, function testing or safely decocking without damaging the firing pin. And A-Zoom training rounds are much more than conventional snap-caps. They are precision CNC machined from solid aluminum to precise cartridge dimensions, then hard anodized for ultra-smooth functioning and long life. Each round has A-Zoom's remarkably durable Dead Cap proven to withstand over three thousand dry fires while protecting the firing pin. Aluminum construction Precision CNC machined Value pack quantities A-Zoom Snap Caps last over 30 times longer than conventional plastic caps.



Attributes

- Name: [A-ZOOM 450 BUSHMASTER SNAP CAP BLUE 2PK](#)
- Manufacturer: [A-ZOOM](#)
- Product no.: 100027951
- Mfr. No.:
- Cartridge: 450 Bushmaster
- Quantity: 2
- Delivery weight: 0.05kg
- Shipping height: 20mm
- Shipping width: 108mm
- Shipping length: 152mm
- UPC: 666692123030

Item details

Made in USA

Table of Contents

- [Startpage](#)
- [Safety Instruction Guide for AZoom Snap Caps Blue Value Packs](#)
- [About Us](#)

Safety Instruction Guide for AZoom Snap Caps Blue Value Packs

Introduction

Thank you for choosing AZoom Snap Caps Blue Value Packs. These snap caps are designed for safety training, function testing, and safely decocking firearms without damaging the firing pin. This guide provides essential safety instructions to ensure safe and effective use of the product in compliance with the EU General Product Safety Regulation (GPSR).

General Safety Guidelines

- Always treat snap caps as if they are live ammunition.
- Keep snap caps out of reach of children and unauthorized users.
- Use snap caps only in a safe and controlled environment.
- Inspect snap caps before use for any signs of damage or wear.
- Do not use snap caps in any firearm that is not designed for their specific caliber.
- Report any unsafe product experiences or accidents to the appropriate authorities.

Specific Safety Precautions for Use

- Ensure that the firearm is unloaded before inserting snap caps.
- Only use snap caps in firearms that are compatible with the 450 Bushmaster cartridge.
- Do not exceed the recommended number of dry fires as indicated by the manufacturer.
- Always follow the manufacturer's instructions for the specific firearm being used.
- Avoid using snap caps for any purpose other than training or function testing.

Instructions for Installation and Usage

1. **Inspect the Snap Caps:** Before use, check each snap cap for any visible damage or defects.
2. **Load the Snap Caps:**
 - Open the action of your firearm.
 - Insert the snap caps into the magazine or chamber as you would with live ammunition.
3. **Conduct Training or Testing:**
 - Follow standard safety protocols for handling firearms.
 - Use the snap caps for dry firing exercises, ensuring a safe environment.
4. **Unloading the Snap Caps:**
 - After training, open the action of the firearm.
 - Remove the snap caps from the magazine or chamber.
5. **Storage:**
 - Store snap caps in a cool, dry place, away from children and unauthorized users.

Disposal Instructions

- Dispose of damaged or worn snap caps according to local regulations.
- Do not throw snap caps in regular household waste if they are damaged.
- Check with local waste management authorities for proper disposal methods.

Contact Information for Further Support

For any safety inquiries or concerns regarding the AZoom Snap Caps Blue Value Packs, please contact your local retailer or refer to the manufacturer's website for more information.

Thank you for prioritizing safety while using AZoom Snap Caps. Your adherence to these guidelines helps ensure a safe and effective training experience.

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk