

AR-15 EJECTION PORT COVER PIN - LUTH-AR AR-15 EJECTION PORT COVER PIN

[Home](#)

Luth-AR factory replacement Ejection Port Cover Pin. Fits standard AR-15 rifles.



Attributes

- Name: [LUTH-AR AR-15 EJECTION PORT COVER PIN](#)
- Manufacturer: [LUTH-AR](#)
- Product no.: 100028057
- Mfr. No.: UR03
- Weapon type: AR-15
- Delivery weight: 0.045kg
- Shipping height: 25mm
- Shipping width: 25mm
- Shipping length: 102mm
- UPC: 859819007829

Item details

Made in USA

Table of Contents

- Startpage
- Safety Instructions for AR15 Ejection Port Cover Pin
- About Us

Safety Instructions for AR15 Ejection Port Cover Pin

Introduction

Thank you for choosing the LuthAR Ejection Port Cover Pin for your AR15 rifle. This product is designed for safe and effective use in standard AR15 rifles. Please read this safety instruction guide carefully to ensure proper installation and usage, as well as to understand the safety measures associated with this product.

General Safety Guidelines

- Always handle firearms with care and ensure they are unloaded when performing any maintenance or installation.
- Familiarize yourself with your firearm's manual and safety features.
- Ensure that the Ejection Port Cover Pin is compatible with your specific AR15 model.
- Keep this product out of reach of children and unauthorized users.
- Regularly inspect the Ejection Port Cover Pin for wear or damage before use.
- In case of any concerns regarding safety or product integrity, refrain from use and seek assistance.

Specific Safety Precautions for Use

- Ensure that the firearm is pointed in a safe direction at all times during installation.
- Avoid using excessive force when installing or removing the Ejection Port Cover Pin.
- Do not modify the Ejection Port Cover Pin or any associated components.
- Wear appropriate safety gear, such as safety glasses, when performing installation.
- Be aware of your surroundings and ensure that no one is in close proximity while you work on your firearm.

Instructions for Installation and Usage

1. Preparation:

- Ensure the firearm is unloaded and safe.
- Gather necessary tools, including a punch tool and hammer.

2. Installation:

- Align the Ejection Port Cover Pin with the designated hole on the AR15 receiver.
- Gently tap the pin into place using the punch tool and hammer. Ensure it is seated properly but do not apply excessive force.
- Verify that the pin is secure and that the Ejection Port Cover operates smoothly.

3. Usage:

- Once installed, regularly check the Ejection Port Cover Pin during routine firearm maintenance.
- If you notice any issues with the functionality of the Ejection Port Cover, remove the pin and inspect for damage.

Disposal Instructions

- Dispose of any defective or damaged Ejection Port Cover Pins in accordance with local regulations.
- Do not dispose of the product in regular household waste. Instead, contact your local waste management authority for proper disposal methods.

Contact Information for Further Support

For any safety inquiries or concerns regarding the LuthAR Ejection Port Cover Pin, please consult your retailer or visit the manufacturer's website for additional resources.

Thank you for your attention to these safety instructions. Your safety and the safety of others depend on your responsible handling and maintenance of your firearm and its components.

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk