

22ARC FIRING PIN SPRING - CMMG 22ARC FIRING PIN SPRING

[Rifle Parts](#) > [Bolt Parts](#) > [Firing Pin Parts](#) > [Firing Pin Springs](#)

Spring, Firing Pin, 22ARC.



Attributes

- Name: [CMMG 22ARC FIRING PIN SPRING](#)
- Manufacturer: [CMMG](#)
- Product no.: 100036088
- Mfr. No.: 22BA4A4
- Model: 22ARC
- Weapon type: CMMG
- Delivery weight: 0.045kg
- Shipping height: 25mm
- Shipping width: 127mm
- Shipping length: 152mm
- UPC: 810046235799

Item details

Made in USA

Table of Contents

- [Startpage](#)
- [Safety Instruction Guide for 22ARC Firing Pin Spring](#)
- [About Us](#)

Safety Instruction Guide for 22ARC Firing Pin Spring

Introduction

Thank you for choosing the 22ARC Firing Pin Spring by CMMG. This guide provides essential safety instructions and guidelines to ensure the safe usage and handling of the product. Please read this manual carefully before use to familiarize yourself with the safety measures and operational procedures.

General Safety Guidelines

- Ensure that the product is used only as intended.
- Always follow the manufacturer's instructions for installation and usage.
- Keep the product out of reach of children and vulnerable individuals.
- Regularly inspect the product for any signs of wear or damage before use.
- In the event of an accident or injury, report it to the appropriate authorities immediately.
- Stay informed about safety recalls by checking the EU's Safety Gate platform.

Specific Safety Precautions for Use

- Avoid using the firing pin spring if it shows any signs of damage or deformation.
- Ensure that the spring is compatible with your firearm model before installation.
- Use protective eyewear during installation and handling to prevent injury.
- Do not modify the firing pin spring in any way; alterations can lead to malfunction and safety risks.
- Always handle the product in a safe environment, free from distractions.

Instructions for Installation and Usage

1. Preparation

- Gather all necessary tools and safety equipment before starting the installation.
- Ensure the firearm is unloaded and in a safe condition.

2. Installation Steps

- Remove the old firing pin spring from the firearm, if applicable.
- Carefully position the new 22ARC firing pin spring in the designated area.
- Ensure it is seated properly and securely.
- Reassemble the firearm according to the manufacturer's instructions.

3. PostInstallation Checks

- After installation, check that the firing pin spring is functioning correctly.
- Perform a function check of the firearm to ensure it operates safely.

4. Usage

- Use the firearm only in accordance with all local laws and regulations.
- Always maintain proper firearm safety practices during operation.

Disposal Instructions

- Dispose of the product in accordance with local regulations regarding hazardous materials.

- Do not dispose of the firing pin spring in general household waste.
- Consult local authorities or waste management services for proper disposal methods.

Contact Information for Further Support

For any inquiries or concerns regarding the safety of your 22ARC Firing Pin Spring, please contact the manufacturer directly. Ensure that you have the product details and any relevant information ready for assistance.

By following these guidelines, you can help ensure the safe use of the 22ARC Firing Pin Spring. Thank you for prioritizing safety and compliance with the EU General Product Safety Regulation.

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk