

SME BULLSEYE LONG RANGE CAMERA - SHOOTING MADE EASY

SME BULLSEYE LONG RANGE CAMERA

[Optics & Mounting](#) > [Action Cameras](#) > [Cameras](#)

A Target Camera Built for Shooting Out to 1 Mile

Want to stretch the legs on your rifle system? If you're shooting paper targets past 300 yards, it can be incredibly difficult to see any kind of results without calling the range cold and making the long trek down to the target and back. If you're shooting at 1,000 yards or even a mile, that becomes even harder to do! Enter the SME Bullseye Camera Systems Sight-In Long Range Camera. The incredibly powerful Sight-In 1 Mile Target Camera System is an all-in-one unit that provides high-definition, real-time video of your target to the shooter.



The weather-resistant construction means it can be used in all environments without issue. Thanks to the free Bullseye Target Manager app available for Android and Apple devices, shooters can use their phone to check targets while they're at the bench. No more calling the line cold to go down and check targets! Each SME Bullseye Camera Systems Sight-In Camera provides high-definition video at 960p and features a built-in locking cantilever and a 1/4-inch tripod mount that you can use on any standard camera tripod. Also included with the kit is a built-in sunshade that prevents lens glare, and LED illumination for use in low-light environments. The camera also has serrated feet for gripping onto rough, uneven terrain.

Attributes

- Name: [SHOOTING MADE EASY SME BULLSEYE LONG RANGE CAMERA](#)
- Manufacturer: [SHOOTING MADE EASY](#)
- Product no.: 100036665
- Mfr. No.: SME-TGTCAM-LR
- Colour: Tan
- Delivery weight: 3.039kg
- Shipping height: 216mm
- Shipping width: 140mm
- Shipping length: 406mm
- UPC: 888151019771

Table of Contents

- Startpage
- SME Bullseye Long Range Camera Safety Instructions
- About Us

SME Bullseye Long Range Camera Safety Instructions

Introduction

Thank you for choosing the SME Bullseye Long Range Camera. This guide provides essential safety instructions to ensure the safe and effective use of your camera system. Please read this document carefully before using the product to familiarize yourself with its features and safety precautions.

General Safety Guidelines

- Ensure the product is used according to the manufacturer's instructions.
- Always use the camera in a safe environment, away from obstacles and hazards.
- Inspect the camera and accessories before use for any signs of damage or wear.
- Keep the camera out of reach of children and vulnerable individuals.
- Be aware of your surroundings when using the camera, especially in outdoor environments.
- Report any unsafe products or accidents to the appropriate authorities.
- Stay updated on safety recalls by checking the EU's Safety Gate platform.

Specific Safety Precautions for Use

- **Weather Resistance:** The camera is designed to be weatherresistant. However, do not expose it to extreme weather conditions without proper protection.
- **WiFi Connection:** Ensure that your mobile device is compatible with the camera's WiFi transmitter. Follow all instructions for connecting your device.
- **Tripod Use:** Always use the camera on a stable surface. If using a tripod, ensure it is properly set up to prevent tipping.
- **Lens Care:** Use the builtin sunshade to prevent lens glare. Regularly clean the lens with a soft cloth to maintain video quality.
- **LowLight Usage:** Utilize the LED illumination feature in lowlight conditions to ensure visibility.
- **Terrain Awareness:** Be cautious when placing the camera on rough or uneven terrain. The serrated feet are designed for grip, but stability is crucial.

Instructions for Installation and Usage

1. Setting Up the Camera:

- Remove the camera from the packaging and inspect it for any damage.
- Attach the camera to a standard camera tripod using the 1/4inch tripod mount.
- If necessary, adjust the builtin locking cantilever to secure the camera in place.

2. Connecting to Your Device:

- Download the Bullseye Target Manager app from the Google Play Store or Apple App Store.
- Turn on the camera and enable the WiFi transmitter.
- On your mobile device, go to WiFi settings and connect to the camera's network.
- Open the Bullseye Target Manager app to start viewing the live video feed.

3. Using the Camera:

- Position the camera at a suitable distance from your target.
- Use the app to monitor your shots without needing to go downrange.
- Adjust the camera angle as needed for optimal target visibility.

4. PostUse Care:

- After use, turn off the camera and disconnect it from your mobile device.
- Store the camera in a safe, dry place away from direct sunlight.

Disposal Instructions

- Dispose of the camera and its components according to local regulations for electronic waste.
- Remove batteries and dispose of them separately, following local guidelines for battery disposal.
- Do not dispose of the camera in regular household waste.

Contact Information for Further Support

For any inquiries or support regarding the SME Bullseye Long Range Camera, please refer to the manufacturer's contact information provided in the product packaging or visit the manufacturer's website.

Thank you for your attention to these safety instructions. Enjoy using your SME Bullseye Long Range Camera!

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk