

GUIDE ROD ASSEMBLY FOR GLOCK® 17 - RIVAL ARMS GUIDE ROD ASSEMBLY GLOCK 17 GEN 4, STAINLESS

[Handgun Parts](#) > [Recoil Parts](#) > [Recoil Spring Guide Rods](#)

Experienced shooters realize plastic guide rods can chip, crack, or break resulting in feeding or ejection failures, flex can also contribute to accuracy problems. Rival Arms™ Guide Rod Assemblies address all of these issues and will provide you a lifetime of reliable service.



Attributes

- Name: [RIVAL ARMS GUIDE ROD ASSEMBLY GLOCK 17 GEN 4, STAINLESS](#)
- Manufacturer: [RIVAL ARMS](#)
- Product no.: 100038496
- Mfr. No.: RA-RA50G111S
- Model: 17,Gen 4
- Weapon type: Glock
- Delivery weight: 0.045kg
- Shipping height: 38mm
- Shipping width: 76mm
- Shipping length: 114mm
- UPC: 788130027097

Item details

Made in USA

US export classification: 0A501.x

Table of Contents

- Startpage
- GUIDE ROD ASSEMBLY FOR GLOCK® 17 RIVAL ARMS
- About Us

GUIDE ROD ASSEMBLY FOR GLOCK® 17 RIVAL ARMS

Introduction

Thank you for choosing the Rival Arms™ Guide Rod Assembly for your Glock® 17 Gen 4. This product is designed to enhance the performance and reliability of your firearm. Please read this safety instruction guide carefully to ensure proper use and maintenance.

General Safety Guidelines

- Ensure the product is used in accordance with the manufacturer's instructions.
- Always treat your firearm as if it is loaded.
- Keep firearms out of reach of children and unauthorized users.
- Regularly inspect your guide rod assembly for signs of wear or damage.
- Report any unsafe products or accidents to the appropriate authorities.
- Stay informed about recalls and safety updates through the EU's Safety Gate platform.

Specific Safety Precautions for Use

- Do not use the guide rod assembly if it shows any signs of cracking, chipping, or other damage.
- Ensure that the guide rod assembly is compatible with your specific model (Glock 17 Gen 4).
- Avoid using excessive force during installation or removal.
- Always wear appropriate safety gear, including eye protection, when handling firearms.
- Be aware of your surroundings and ensure a safe environment when using your firearm.

Instructions for Installation and Usage

1. Preparation

- Ensure your firearm is unloaded and pointed in a safe direction.
- Gather necessary tools: a punch tool and a small hammer.

2. Installation

- Remove the slide from the frame of the Glock 17 Gen 4.
- Carefully remove the old guide rod assembly by pushing out the retaining pin.
- Insert the Rival Arms™ Guide Rod Assembly into the slide, ensuring it is seated properly.
- Replace the retaining pin to secure the guide rod assembly in place.

3. Usage

- After installation, perform a function check to ensure proper operation.
- Test the firearm in a safe and controlled environment before regular use.
- Regularly clean and maintain the guide rod assembly to ensure optimal performance.

Disposal Instructions

- Dispose of any damaged or old guide rod assemblies in accordance with local regulations for hazardous materials.
- Do not throw away in regular household waste.
- Consider recycling options if available.

Contact Information for Further Support

For any inquiries or support regarding the Rival Arms™ Guide Rod Assembly, please refer to the manufacturer's contact information, which can be found on the product packaging or the manufacturer's website.

Thank you for prioritizing safety and compliance with the EU General Product Safety Regulation. Your responsible usage contributes to a safer environment for all.

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk