

SMOKEWAGON REVOLVER - SMOKEWAGON 5.5" .45LC TUNED

Exclusively from Taylor's & Co., The Smoke Wagon™ is a second-generation, stagecoach-style, single-action revolver. It boasts a low-sitting hammer and wider-style sights that allow for faster sight acquisition. It also features a blue finish with a case-hardened frame, and a thin, richly detailed, checkered grip for comfort and improved aim. All of the previous features are available on both the standard and Taylor Tuned version of The Smoke Wagon™. Taylor Tuned actions are performed by our own in-house gunsmiths and feature: hand polishing, exact timing, and lighter hammer/trigger pull with our custom springs. The Taylor Tuned Smoke Wagon™ features one of the smoothest hammer and trigger pulls on the market.



Attributes

- Name: SMOKEWAGON 5.5" .45LC TUNED
- Manufacturer: TAYLORS & COMPANY
- Product no.: 100039995
- Mfr. No.: 4110DE
- Action Type: Revolver
- Barrel Length: 5.5"
- Capacity: 6-Round
- Finish: Blued
- Front Sight: Fixed
- Length: 11.1"
- Magazine Included: NA
- Magazine Type: Fixed
- Make: Taylor's & Co. Inc
- Model: Smokewagon
- Muzzle: Plain
- Náboje: 45 (Long) Colt
- Rear Sight: Fixed
- Stock Material: Walnut
- Weight: 2.5 lbs
- Delivery weight: 1.383kg
- Shipping height: 51mm
- Shipping width: 191mm
- Shipping length: 406mm
- UPC: 839665004784

Item details

US export classification: 0A501.a

Table of Contents

- [Startpage](#)
- [English: Smoke Wagon Revolver Safety Instructions](#)
- [Český: Návod na bezpečnostní pokyny pro revolver SMOKEWAGON TAYLORS & COMPANY](#)

Smoke Wagon Revolver Safety Instructions

Introduction

Thank you for choosing the Smoke Wagon™ Revolver from Taylor's & Co. This guide is designed to provide you with essential safety instructions to ensure the safe use and handling of your firearm. Please read this manual carefully and keep it for future reference.

General Safety Guidelines

- Always treat the revolver as if it is loaded.
- Keep the revolver pointed in a safe direction at all times.
- Keep your finger off the trigger until you are ready to shoot.
- Be aware of your target and what lies beyond it.
- Store the revolver in a secure location, out of reach of children and unauthorized users.
- Use only the recommended ammunition for this revolver.
- Regularly inspect your revolver for any signs of wear or damage.
- Never modify your revolver without consulting a qualified gunsmith.

Specific Safety Precautions for Use

- **Handling:** Always handle your revolver with care. If you are unsure how to handle it safely, seek guidance from a qualified instructor.
- **Loading and Unloading:** Follow proper procedures for loading and unloading your revolver. Ensure the revolver is pointed in a safe direction during these processes.
- **Shooting:** Use appropriate hearing and eye protection when shooting. Ensure that the shooting area is clear of people and obstacles.
- **Cleaning:** Clean your revolver regularly according to the manufacturer's instructions. Ensure it is unloaded before cleaning.
- **Transporting:** When transporting your revolver, ensure it is unloaded and stored in a secure case.

Instructions for Installation and Usage

1. Loading the Revolver:

- Open the cylinder and ensure it is empty.
- Load one cartridge into each chamber of the cylinder.
- Close the cylinder securely before handling or shooting.

2. Firing the Revolver:

- Ensure you are in a safe shooting position.
- Grip the revolver firmly and aim at your target.
- With your finger off the trigger, cock the hammer back if necessary.
- Squeeze the trigger gently to fire.

3. Unloading the Revolver:

- Point the revolver in a safe direction.
- Open the cylinder and remove all cartridges.
- Check each chamber to ensure it is empty.

4. Cleaning the Revolver:

- Ensure the revolver is unloaded.
- Use a cleaning kit suitable for firearms to clean the barrel and other components.
- Store the revolver in a dry place after cleaning.

Disposal Instructions

When disposing of your Smoke Wagon™ Revolver, follow local regulations regarding firearms disposal. If you need to dispose of the revolver, consider the following options:

- Contact a local firearms dealer or law enforcement agency for guidance on safe disposal.
- Do not dispose of the revolver in regular household waste.

Contact Information for Further Support

For any safety inquiries or concerns regarding your Smoke Wagon™ Revolver, please contact Taylor's & Co. or refer to your local firearms authority.

By following these safety instructions, you can help ensure a safe and enjoyable experience with your Smoke Wagon™ Revolver. Always prioritize safety and responsibility when handling firearms.

Návod na bezpečnostní pokyny pro revolver SMOKEWAGON TAYLORS & COMPANY

Úvod

Děkujeme, že jste si zakoupili revolver SMOKEWAGON od Taylor's & Co. Tento dokument obsahuje důležité bezpečnostní pokyny a informace, které vám pomohou zajistit bezpečné používání vašeho revolveru. Je důležité, abyste si tyto pokyny pečlivě přečetli a dodržovali je.

Obecné bezpečnostní pokyny

- Před použitím revolveru se důkladně seznámte s jeho funkcemi a ovládacími prvky.
- Vždy zacházejte s revolverem jako s nabitým, i když víte, že je vybitý.
- Nikdy nesměřujte hlaveň revolveru na nic, co nechcete zasáhnout.
- Při použití revolveru noste ochranné brýle a sluchátka.
- Udržujte revolver mimo dosah dětí a nezkušených osob.
- Před každým použitím zkontrolujte, zda je revolver v dobrém stavu a funkční.
- Dodržujte místní zákony a předpisy týkající se vlastnictví a používání střelných zbraní.

Specifické bezpečnostní opatření při používání

- Před nabíjením revolveru se ujistěte, že je zajištěn bezpečný prostor.
- Používejte pouze doporučené náboje (45 Long Colt) pro vaše revolver.
- Nikdy nenabíjejte revolver, pokud je na veřejném místě nebo v blízkosti dalších osob.
- Pokud dojde k poruše, okamžitě přestaňte používat revolver a nechte jej zkontrolovat odborníkem.
- Při střelbě dodržujte bezpečnou vzdálenost od ostatních osob a překážek.

Pokyny pro instalaci a používání

- Před prvním použitím si prostudujte uživatelský manuál a naučte se, jak revolver správně používat.
- Revolver držte pevně, ale bez zbytečného napětí, a ujistěte se, že máte správný úchop.
- Při zaměřování se snažte o stabilní postoj a klidné dýchání.
- Po každém výstřelu zkontrolujte, zda je revolver v pořádku a zda nedošlo k žádné poruše.
- Po dokončení střelby revolver důkladně vyčistěte a uložte na bezpečné místo.

Pokyny pro likvidaci

- Při likvidaci revolveru se obraťte na odborníka nebo místní úřady, které se zabývají likvidací střelných zbraní.
- Nikdy se nesnažte revolver zlikvidovat sami, pokud neznáte správné postupy.

Kontakt pro další podporu

Pro další informace a podporu se obraťte na autorizovaného prodejce nebo výrobce. Ujistěte se, že máte k dispozici všechny relevantní informace o produktu.

Dodržováním těchto pokynů zajistíte nejen svou bezpečnost, ale i bezpečnost ostatních. Děkujeme, že dodržujete bezpečnostní standardy a užíváte si svůj revolver SMOKEWAGON!