

IMPULSE HOG HUNTER6.5 CREEDMOOR

When speed is the name of the game, the straight-pull action at the heart of IMPULSE Hog Hunter delivers like no other bolt-action can. This new American made Savage rifle is instinctive and fast—and every inch of the rifle encompasses breakthrough technology for repeat accuracy and enhanced safety. IMPULSE Hog Hunter is built for long range stopping power.



Attributes

- Name: IMPULSE HOG HUNTER6.5 CREEDMOOR
- Manufacturer: SAVAGE ARMS
- Product no.: 100041823
- Mfr. No.: 57654
- Action Type: Bolt Action
- Barrel Length: 20"
- Capacity: 4+1-Round
- Finish: Blued
- Front Sight: None
- Length: 37.75"
- Magazine Included: 1 x 4-Round
- Magazine Type: Removable
- Make: Savage Arms
- Model: Impulse Hog Hunter
- Muzzle: Threaded
- Náboje: 6.5 Creedmoor
- Rear Sight: None
- Stock Material: Polymer
- Weight: 8.5 lbs
- Delivery weight: 5.318kg
- Shipping height: 89mm
- Shipping width: 216mm
- Shipping length: 1,232mm
- UPC: 011356576545

Item details

Made in USA

US export classification: 0A501.a

Table of Contents

- [Startpage](#)
- [English: IMPULSE HOG HUNTER Safety Instruction Guide](#)
- [Český: Návod k použití a bezpečnostní pokyny pro IMPULSE HOG HUNTER SAVAGE ARMS 6.5 CREEDMOOR](#)

IMPULSE HOG HUNTER Safety Instruction Guide

Introduction

Thank you for choosing the IMPULSE Hog Hunter, a highperformance rifle designed for precision and speed. This safety instruction guide is designed to help you use your firearm safely and responsibly. Please read this guide carefully before using your rifle.

General Safety Guidelines

- Always treat every firearm as if it is loaded.
- Keep your finger off the trigger until you are ready to shoot.
- Never point the firearm at anything you do not intend to shoot.
- Be aware of your surroundings and ensure that you have a clear line of sight before firing.
- Store your firearm in a secure place, out of reach of children and unauthorized users.
- Use only the recommended ammunition for your rifle.
- Regularly inspect your firearm for signs of wear or damage.
- Always wear appropriate eye and ear protection when shooting.
- Follow all local laws and regulations regarding firearm ownership and usage.

Specific Safety Precautions for Use

- Ensure the safety is engaged until you are ready to fire.
- Do not modify your firearm in any way that could affect its safety or performance.
- Avoid using the rifle in wet or damp conditions to prevent rust and corrosion.
- Always check the barrel for obstructions before loading.
- If a misfire occurs, keep the rifle pointed in a safe direction for at least 30 seconds before attempting to unload.
- Be cautious of the muzzle direction when loading and unloading the rifle.

Instructions for Installation and Usage

1. Installation of Accessories:

- Ensure the firearm is unloaded before installing any accessories.
- Follow the manufacturer's instructions for mounting scopes or other attachments.

2. Loading the Rifle:

- Open the bolt and visually inspect the chamber to confirm it is empty.
- Insert the magazine into the rifle until it clicks into place.
- Pull the bolt back and release it to chamber a round.
- Engage the safety until you are ready to fire.

3. Firing the Rifle:

- Stand in a stable shooting position with your feet shoulderwidth apart.
- Hold the rifle firmly but not excessively tight.
- Aim at your target and ensure the area is clear.
- Disengage the safety and squeeze the trigger smoothly.

4. Unloading the Rifle:

- Point the rifle in a safe direction.
- Engage the safety and remove the magazine.
- Open the bolt to eject any chambered round.
- Visually inspect the chamber to ensure it is empty.

Disposal Instructions

- Dispose of your firearm responsibly and in accordance with local laws.
- Contact your local authorities for guidance on safe disposal methods.
- Do not dispose of ammunition in regular trash. Follow hazardous waste disposal guidelines.

Contact Information for Further Support

For any inquiries regarding safety or product support, please reach out to your local retailer or manufacturer. Always ensure you are following the latest safety guidelines and regulations.

Thank you for choosing the IMPULSE Hog Hunter. Your safety and the safety of others depend on your responsible use of this firearm.

Návod k použití a bezpečnostní pokyny pro IMPULSE HOG HUNTER SAVAGE ARMS 6.5 CREEDMOOR

Úvod

Děkujeme vám za zakoupení pušky IMPULSE Hog Hunter od společnosti Savage Arms. Tento návod vám poskytne důležité informace o bezpečném používání, instalaci a likvidaci této pušky. Před použitím si prosím důkladně přečtěte všechny pokyny a bezpečnostní upozornění.

Obecné bezpečnostní pokyny

- Před použitím pušky si důkladně přečtěte a porozumějte všem pokynům.
- Vždy zacházejte s puškou jako s nabitou, dokud si nejste jisti, že je prázdná.
- Udržujte pušku mimo dosah dětí a zranitelných osob.
- Při používání pušky dodržujte všechny platné zákony a předpisy.
- Používejte pouze doporučené náboje a příslušenství.
- Zkontrolujte, zda je puška v dobrém stavu před každým použitím.
- Nikdy nesměřujte hlaveň pušky na něco, co nechcete zasáhnout.

Specifické bezpečnostní opatření při používání

- Před nabitím pušky se ujistěte, že je v bezpečné oblasti a že nemáte žádné překážky v okolí.
- Při střelbě noste ochranné brýle a sluchátka.
- Nikdy nestřílejte, pokud nejste plně soustředěni a připraveni.
- V případě selhání náboje dodržujte doporučené postupy pro bezpečné odstranění.
- Při manipulaci s puškou se vyhněte alkoholu a jiným omamným látkám.

Pokyny pro instalaci a používání

1. **Kontrola obsahu balení:** Zkontrolujte, zda jsou všechny součásti pušky přítomny a nepoškozené.
2. **Nabíjení pušky:**
 - Otevřete závěr a ujistěte se, že je komora prázdná.
 - Vložte náboje do zásobníku a zajistěte, aby byly správně usazený.
 - Zasuňte zásobník zpět do pušky.
3. **Zaměřování:**
 - Ujistěte se, že je puška stabilní a v klidné poloze.
 - Použijte vhodné mířidlo nebo optiku pro přesné zaměření.
4. **Střelba:**
 - Zkontrolujte okolí a ujistěte se, že je bezpečné střílet.
 - Stiskněte spoušť jemně a kontrolovaně.
5. **Údržba:**
 - Pravidelně čistěte pušku podle doporučení výrobce.
 - Zkontrolujte všechny pohyblivé části a ujistěte se, že fungují správně.

Pokyny pro likvidaci

- Pušku a její součásti likvidujte v souladu s místními předpisy o odpadech.
- Nepokoušejte se o likvidaci pušky sami, pokud jste si jisti, že je stále funkční.
- V případě poškození nebo selhání se obraťte na autorizovaný servis.

Kontaktní informace pro další podporu

Pro jakékoli dotazy týkající se bezpečnosti produktu, údržby nebo použití se obraťte na autorizovaného prodejce nebo servisní středisko. Ujistěte se, že máte k dispozici informace o produktu, včetně modelu a sériového čísla.

Závěr

Dodržováním těchto pokynů zajistíte bezpečné a efektivní používání vaší pušky IMPULSE Hog Hunter. Vždy mějte na paměti zásady bezpečnosti při manipulaci se střelnými zbraněmi a nezapomeňte se informovat o všech platných zákonech a regulacích. Buďte zodpovědní a užívejte si bezpečné střelby.