

IMPULSE HOG HUNTER 300 WIN MAG

When speed is the name of the game, the straight-pull action at the heart of IMPULSE Hog Hunter delivers like no other bolt-action can. This new American made Savage rifle is instinctive and fast—and every inch of the rifle encompasses breakthrough technology for repeat accuracy and enhanced safety. IMPULSE Hog Hunter is built for long range stopping power.



Attributes

- Name: IMPULSE HOG HUNTER 300 WIN MAG
- Manufacturer: SAVAGE ARMS
- Product no.: 100041825
- Mfr. No.: 57656
- Action Type: Bolt Action
- Barrel Length: 24"
- Capacity: 3+1-Round
- Finish: Blued
- Front Sight: None
- Length: 45.5"
- Magazine Included: 1 x 3-Round
- Magazine Type: Removable
- Make: Savage Arms
- Model: Impulse Hog Hunter
- Muzzle: Threaded
- Náboje: 300 Winchester Magnum
- Rear Sight: None
- Stock Material: Polymer
- Weight: 9.1 lbs
- Delivery weight: 4.128kg
- UPC: 011356576569

Item details

Made in USA

US export classification: 0A501.a

Table of Contents

- [Startpage](#)
- [English: IMPULSE HOG HUNTER Safety Instruction Guide](#)
- [Český: Návod k bezpečnému používání IMPULSE HOG HUNTER 300 WIN MAG](#)

IMPULSE HOG HUNTER Safety Instruction Guide

Introduction

Thank you for choosing the IMPULSE HOG HUNTER 300 WIN MAG. This guide provides essential safety instructions to ensure the safe and effective use of your firearm. Please read this manual carefully before using the product and keep it for future reference.

General Safety Guidelines

- Always treat the firearm as if it is loaded.
- Keep the muzzle pointed in a safe direction at all times.
- Keep your finger off the trigger until you are ready to shoot.
- Be aware of your target and what is beyond it.
- Store the firearm in a secure location, out of reach of children and unauthorized persons.
- Regularly inspect the firearm for any signs of wear or damage.
- Use only the recommended ammunition type specified in this manual.
- Do not modify the firearm in any way that could affect its safety or performance.
- Follow all local laws and regulations regarding firearm ownership and use.

Specific Safety Precautions for Use

- Ensure that the firearm is unloaded when not in use.
- Always wear appropriate eye and ear protection when shooting.
- Do not shoot at hard surfaces or water to prevent ricochets.
- Be cautious of your surroundings and ensure that you have a clear shooting area.
- Avoid using the firearm under the influence of drugs or alcohol.
- If you experience a misfire, keep the firearm pointed downrange for at least 30 seconds before attempting to clear the chamber.

Instructions for Installation and Usage

1. Assembly:

- Remove the firearm from its packaging.
- Ensure that the firearm is unloaded.
- Attach the scope or any other accessories as per the manufacturer's instructions.

2. Loading the Firearm:

- Open the bolt and visually inspect the chamber to ensure it is empty.
- Insert the magazine into the magazine well until it clicks into place.
- Load the appropriate ammunition into the magazine, ensuring it is seated correctly.

3. Firing the Firearm:

- Ensure that the firearm is pointed in a safe direction.
- Chamber a round by pulling back the bolt and releasing it.
- Take aim at your target.
- Squeeze the trigger gently to fire the firearm.

4. Unloading the Firearm:

- Point the firearm in a safe direction.
- Open the bolt and remove the magazine.
- Visually inspect the chamber to ensure it is empty.

5. Cleaning and Maintenance:

- Clean the firearm regularly to ensure optimal performance.
- Use a cleaning kit suitable for your firearm type.
- Follow the manufacturer's recommendations for cleaning frequency and techniques.

Disposal Instructions

- Dispose of any unused ammunition according to local regulations.
- When disposing of the firearm, contact a licensed dealer or local authorities for proper disposal methods.
- Ensure that the firearm is rendered inoperable before disposal.

Contact Information for Further Support

For any inquiries regarding safety, usage, or maintenance of the IMPULSE HOG HUNTER, please refer to your local authorized dealer or the manufacturer's customer service.

By adhering to these safety guidelines and instructions, you can ensure a safe and enjoyable experience with your IMPULSE HOG HUNTER 300 WIN MAG. Always prioritize safety and responsibility in all your firearm-related activities.

Návod k bezpečnému používání IMPULSE HOG HUNTER 300 WIN MAG

Úvod

Děkujeme, že jste si zakoupili pušku IMPULSE Hog Hunter 300 Win Mag od společnosti Savage Arms. Tento dokument obsahuje důležité informace o bezpečném používání produktu, které jsou v souladu s evropským nařízením o obecné bezpečnosti výrobků (GPSR). Prosím, pečlivě si přečtěte a dodržujte všechny pokyny, abyste zajistili bezpečné a efektivní používání vaší pušky.

Obecné bezpečnostní pokyny

- Zajistěte, aby puška byla vždy uchovávána mimo dosah dětí a nezletilých osob.
- Před každým použitím zkontrolujte, zda je puška v dobrém stavu a zda všechny její části fungují správně.
- Nikdy neukazujte pušku na někoho jiného a vždy ji směřujte bezpečně.
- Používejte pouze doporučené náboje a dodržujte pokyny výrobce.
- Při používání pušky noste ochranné brýle a sluchátka.
- Po každém použití pušku řádně vyčistěte a uložte na bezpečné místo.

Specifické bezpečnostní opatření pro použití

- Před nabitím pušky se ujistěte, že je zajištěna bezpečnostní pojistka.
- Nikdy nenabíjejte pušku, pokud nejste připraveni k jejímu použití.
- Před vystřelením se ujistěte, že je cíl jasně viditelný a že za cílem není žádná překážka.
- V případě jakýchkoliv problémů nebo závad během používání se okamžitě obraťte na odborníka.

Pokyny pro instalaci a používání

- Před použitím si přečtěte návod k obsluze a seznámte se s funkcemi pušky.
- Ujistěte se, že je puška správně sestavena a že všechny části jsou pevně připojeny.
- Při nastavování pušky na střelnici dodržujte všechny bezpečnostní pokyny a předpisy.
- Po použití pušku vždy řádně vyčistěte a uložte ji na bezpečné místo.

Pokyny pro likvidaci

- Po skončení životnosti pušky ji zlikvidujte v souladu s místními předpisy o odpadech.
- Nikdy nevyhazujte pušku do běžného odpadu. Vždy se obraťte na odborníka, který vám pomůže s bezpečnou likvidací.

Kontakt pro další podporu

Pokud máte jakékoliv otázky nebo potřebujete další informace, obraťte se na výrobce nebo autorizovaného prodejce. Všechny výrobky musí mít kontaktní místo v EU pro dotazy týkající se bezpečnosti.

Závěr

Dodržováním těchto pokynů zajistíte bezpečné používání vaší pušky IMPULSE Hog Hunter 300 Win Mag. V případě jakýchkoliv nebezpečných situací nebo problémů s produktem se neváhejte obrátit na příslušné úřady a informujte se o možných aktualizacích týkajících se výrobků na platformě Safety Gate EU. Děkujeme, že dbáte na bezpečnost a odpovědnost při používání našich produktů.