

SIGHT ADJUSTMENT TOOL - TROY INDUSTRIES SIGHT ADJUSTMENT TOOL

[Gunsmith Tools](#) > [Sight & Scope Installation Tools](#) > [Sight Adjusting Tools](#)

Easily adjust elevation on Troy Front M4 and HK Style BattleSights™ and windage on Troy Front and Rear BattleSights with Troy's BattleSight Adjustment Tool.



Attributes

- Name: [TROY INDUSTRIES SIGHT ADJUSTMENT TOOL](#)
- Manufacturer: [TROY INDUSTRIES](#)
- Product no.: 100044362
- Mfr. No.: ST00-ADJ-000T-00
- Delivery weight: 0.041kg
- Shipping height: 13mm
- Shipping width: 76mm
- Shipping length: 102mm
- UPC: 812699010884

Item details

Made in USA

Table of Contents

- Startpage
- SIGHT ADJUSTMENT TOOL SAFETY INSTRUCTION GUIDE
- About Us

SIGHT ADJUSTMENT TOOL SAFETY INSTRUCTION GUIDE

Introduction

Thank you for choosing the SIGHT ADJUSTMENT TOOL from TROY INDUSTRIES. This guide provides essential safety instructions and guidelines to ensure the safe and effective use of this product. Please read this manual carefully before using the tool.

General Safety Guidelines

- Ensure that the tool is used only for its intended purpose: adjusting elevation and windage on Troy BattleSights.
- Keep the tool out of reach of children and unauthorized users.
- Regularly inspect the tool for any signs of damage or wear before use.
- Do not use the tool if it appears damaged or malfunctioning.
- Always follow local laws and regulations regarding the use of sight adjustment tools.

Specific Safety Precautions for Use

- Use the tool in a welllit area to ensure visibility during adjustments.
- Wear appropriate eye protection when using the tool to prevent injury from any accidental slips or debris.
- Do not apply excessive force when adjusting sights, as this may damage the tool or the sights themselves.
- Ensure that the firearm is unloaded and pointed in a safe direction before making any adjustments.
- Avoid using the tool in wet or damp conditions to prevent slipping and ensure a secure grip.

Instructions for Installation and Usage

1. Preparation

- Ensure that the firearm is unloaded and pointed in a safe direction.
- Gather all necessary tools and materials, including the SIGHT ADJUSTMENT TOOL.

2. Adjusting Elevation on Troy Front M4 and HK Style BattleSights

- Locate the elevation adjustment knob on the sight.
- Place the SIGHT ADJUSTMENT TOOL onto the elevation adjustment knob.
- Turn the tool clockwise to raise the sight and counterclockwise to lower it.
- Make small adjustments and check the sight alignment frequently.

3. Adjusting Windage on Troy Front and Rear BattleSights

- Identify the windage adjustment knob on the sight.
- Position the SIGHT ADJUSTMENT TOOL on the windage adjustment knob.
- Rotate the tool clockwise to move the sight to the right and counterclockwise to move it to the left.
- Again, make incremental adjustments and verify alignment regularly.

4. PostAdjustment Check

- After making adjustments, ensure that the sights are securely in place and functioning correctly.
- Test the firearm in a safe environment to confirm the adjustments are accurate.

Disposal Instructions

- Dispose of the SIGHT ADJUSTMENT TOOL in accordance with local regulations.
- Do not dispose of the tool in regular household waste if it is damaged.
- Consider recycling options for metal parts if applicable.

Contact Information for Further Support

For any safety inquiries or additional support regarding the SIGHT ADJUSTMENT TOOL, please refer to the manufacturer's contact information provided with the product packaging.

Thank you for your attention to these safety instructions. Enjoy using your SIGHT ADJUSTMENT TOOL responsibly and safely.

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk