

AR-15 DISCONNECT SPRING - CMMG AR-15 DISCONNECT SPRING

[Rifle Parts](#) > [Triggers Parts](#) > [Disconnecter Parts](#) > [Disconnecter Springs](#)

Replacement AR-15 Disconnect Spring.



Attributes

- Name: [CMMG AR-15 DISCONNECT SPRING](#)
- Manufacturer: [CMMG](#)
- Product no.: 100044610
- Mfr. No.: 55CA728
- Weapon type: AR-15
- Delivery weight: 0.009kg
- Shipping height: 6mm
- Shipping width: 121mm
- Shipping length: 178mm
- UPC: 810046231319

Item details

Made in USA

Table of Contents

- [Startpage](#)
- [Safety Instruction Guide for AR15 Disconnect Spring](#)
- [About Us](#)

Safety Instruction Guide for AR15 Disconnect Spring

Introduction

Thank you for choosing the AR15 Disconnect Spring from CMMG. This guide provides important safety information and instructions to ensure the safe use and installation of the product. Please read this document carefully before use.

General Safety Guidelines

- Always handle firearms and firearm components with care and respect.
- Ensure that the product is compatible with your firearm model before installation.
- Store the product in a safe, dry place away from children and unauthorized users.
- Regularly inspect the product for signs of wear or damage before use.
- If you experience any issues or concerns regarding the product, discontinue use immediately and seek assistance.

Specific Safety Precautions for Use

- Only use the AR15 Disconnect Spring in accordance with the manufacturer's guidelines.
- Ensure that the firearm is unloaded and pointed in a safe direction during installation.
- Avoid contact with the spring when the firearm is being assembled or disassembled to prevent injury.
- Do not modify the spring or use it in any way that is not intended by the manufacturer.
- Be aware of your surroundings and ensure that no one is in close proximity when handling the firearm.

Instructions for Installation and Usage

1. Preparation:

- Ensure that the firearm is unloaded and in a safe condition.
- Gather necessary tools for installation, such as a punch and hammer.

2. Installation Steps:

- Remove the upper and lower receiver from the firearm.
- Locate the disconnect spring compartment in the lower receiver.
- Carefully remove the old disconnect spring if applicable.
- Insert the new AR15 Disconnect Spring into the designated area, ensuring proper alignment.
- Reassemble the firearm, ensuring all components are securely in place.

3. PostInstallation:

- Conduct a function check to ensure the firearm operates correctly.
- Store the firearm in a safe location when not in use.

Disposal Instructions

- Dispose of the product in accordance with local regulations for hazardous materials.
- Do not dispose of the product in household waste.
- Contact local waste management authorities for guidance on proper disposal methods.

Contact Information for Further Support

For any inquiries or further assistance regarding the AR15 Disconnect Spring, please refer to the manufacturer's contact details provided on the packaging or product documentation.

This guide is designed to help you safely use and install the AR15 Disconnect Spring. Following these guidelines will help ensure your safety and the proper functioning of your firearm. Thank you for your attention to these important safety measures.

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk