

LIBERATOR II MINI RED DOT SIGHT - SWAMPFOX OPTICS

LIBERATOR II 1X22MM 2 MOA MINI GREEN DOT BLACK

[Optics & Mounting](#) > [Electronic Sights](#) > [Red Dot Sights](#)

Liberator II keeps everything we liked about the original Liberator, while stuffing the inside with upgraded technology, like new emitters with greatly improved battery life and Shake 'N Wake motion sensing auto on/off. The first two brightness settings are night vision compatible, with the following 8 further settings daylight visible. Liberator II ships with two 1913 MIL-STD Picatinny mounts for use on a variety of platforms and the scope body is compatible with industry standard micro dot mounts. Small and light but tough, Liberator II is rated for 800 Gs of shock, so it's a great fit for 12 gauge shotguns and .308 rifles. Liberator II is waterproof, fog resistant and features hydrophobic & anti-scratch coatings on the anti-glare lenses.



Attributes

- Name: [SWAMPFOX OPTICS LIBERATOR II 1X22MM 2 MOA MINI GREEN DOT BLACK](#)
- Manufacturer: [SWAMPFOX OPTICS](#)
- Product no.: 100047726
- Mfr. No.: RDLR122-2GD
- Battery Life: 10000 hours
- Brightness Settings: 10 settings
- Click Value: 2 MOA
- Click Value: 2 MOA
- Finish: Black
- Power Supply: CR 2032
- Reticle: Green Dot
- Weight: 3.49 oz
- Delivery weight: 0.372kg
- Shipping height: 83mm
- Shipping width: 95mm
- Shipping length: 127mm
- UPC: 889157001975

Item details

US export classification: 0A504.c

Table of Contents

- Startpage
- Safety Instruction Guide for LIBERATOR II MINI RED DOT SIGHT
- About Us

Safety Instruction Guide for LIBERATOR II MINI RED DOT SIGHT

Introduction

Thank you for choosing the LIBERATOR II MINI RED DOT SIGHT from Swampfox Optics. This guide provides essential safety instructions and information to ensure the safe use and maintenance of your sight. Please read this guide carefully before using the product.

General Safety Guidelines

To ensure your safety and the safety of others, please follow these guidelines:

- Ensure that all users are familiar with the operation of the LIBERATOR II MINI RED DOT SIGHT.
- Always handle the sight with care to avoid damage.
- Keep the sight away from children and unauthorized users.
- Regularly check the sight for any signs of damage or malfunction.
- Use the sight only for its intended purpose as specified in this guide.

Specific Safety Precautions for Use

When using the LIBERATOR II MINI RED DOT SIGHT, please observe the following safety precautions:

- **Battery Safety:**

- Use only the specified CR 2032 battery.
- Do not attempt to recharge nonrechargeable batteries.
- Dispose of used batteries in accordance with local regulations.

- **Mounting and Installation:**

- Ensure that the sight is securely mounted on the firearm before use.
- Follow the manufacturer's instructions for mounting to avoid accidents.

- **Environmental Considerations:**

- The sight is waterproof and fog resistant; however, avoid exposing it to extreme conditions for prolonged periods.
- Clean the lenses with a soft, dry cloth to prevent scratching.

- **Shock Resistance:**

- The sight is rated for 800 Gs of shock; however, avoid dropping or subjecting it to unnecessary impact.

- **Night Vision Compatibility:**

- Use the first two brightness settings for night vision applications only. Ensure the sight is set to an appropriate brightness for the environment.

Instructions for Installation and Usage

To properly install and use the LIBERATOR II MINI RED DOT SIGHT, follow these steps:

1. Installation:

- Select a suitable mounting platform (e.g., 1913 MILSTD Picatinny rail).
- Align the sight with the rail and secure it using the included mounts.
- Tighten the mounting screws to ensure a stable fit.

2. Powering On:

- Insert a fully charged CR 2032 battery into the battery compartment.
- Turn on the sight by pressing the power button.

3. Adjusting Brightness:

- Use the brightness adjustment buttons to select the desired brightness level.
- The first two settings are for night vision; the next eight settings are for daylight use.

4. Zeroing the Sight:

- To zero the sight, follow the specific instructions provided in the product manual regarding windage and elevation adjustments.

5. Regular Maintenance:

- Periodically check and clean the lenses.
- Ensure all mounting hardware is secure and free from rust or corrosion.

Disposal Instructions

When disposing of the LIBERATOR II MINI RED DOT SIGHT and its components, please follow these guidelines:

- **Electronic Waste:** Do not dispose of the sight in regular household waste. Follow local regulations for electronic waste disposal.
- **Batteries:** Dispose of used batteries in designated battery recycling locations.

Contact Information for Further Support

For any inquiries regarding the LIBERATOR II MINI RED DOT SIGHT, including safety concerns or product support, please refer to the manufacturer's website or customer service resources. It is essential to have an EU-based contact for any safety inquiries.

Conclusion

The LIBERATOR II MINI RED DOT SIGHT is designed for reliable performance and safety. By following the instructions and guidelines in this manual, you can ensure safe usage and prolong the life of your sight. Thank you for your attention to safety, and enjoy your experience with the LIBERATOR II MINI RED DOT SIGHT.

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk