

AR15A4 EXTRACTOR PIN - COLT AR15A4 EXTRACTOR PIN

[Home](#)

FITS: AR-15 Accurized HBAR, .223; AR-15 Government Carbine, .223; AR-15 Match Target, .223; AR-15 Match Target Competition HBAR, .223; AR-15 Match Target Competition HBAR II, .223; AR-15 Match Target HBAR, .223; AR-15 Match Target Lightweig

AR15A4 EXTRACTOR PIN



Attributes

- Name: [COLT AR15A4 EXTRACTOR PIN](#)
- Manufacturer: [COLT](#)
- Product no.: 160304020
- Mfr. No.: 61563
- Model: AR-15,M16,AR-15/M4
- Weapon type: Colt,AR-15
- Delivery weight: 0.005kg
- Shipping width: 83mm
- Shipping length: 146mm

Item details

Made in USA

Table of Contents

- [Startpage](#)
- [AR15A4 Extractor Pin Safety Instructions](#)
- [About Us](#)

AR15A4 Extractor Pin Safety Instructions

Introduction

Thank you for choosing the AR15A4 Extractor Pin by Colt. This safety instruction guide is designed to provide you with essential information regarding the safe use, installation, and disposal of the product. Please read this guide carefully to ensure your safety and compliance with EU General Product Safety Regulation (GPSR).

General Safety Guidelines

- Always ensure that you are using the AR15A4 Extractor Pin in accordance with the manufacturer's specifications.
- Keep the product out of reach of children and vulnerable individuals.
- Regularly inspect the extractor pin for any signs of wear or damage before use.
- Always follow local laws and regulations regarding the use and installation of firearm components.
- If you encounter any issues or have safety concerns, report them to the appropriate authorities.

Specific Safety Precautions for Use

- Ensure that you are wearing appropriate safety gear, including eye protection, when handling or installing the extractor pin.
- Do not attempt to modify or alter the extractor pin in any way.
- When installing the extractor pin, ensure that the firearm is unloaded and pointed in a safe direction.
- Avoid using the extractor pin if it shows any signs of damage or if it does not fit properly.
- Be aware of your surroundings during installation and use to prevent accidents.

Instructions for Installation and Usage

1. Preparation:

- Ensure that the firearm is unloaded and in a safe condition.
- Gather necessary tools for installation, including a punch tool and a hammer.

2. Installation Steps:

- Locate the extractor pin area on your Colt AR15/M4 or M16 model.
- Align the extractor pin with the hole in the bolt carrier group.
- Using the punch tool, gently tap the extractor pin into place with the hammer.
- Ensure that the pin is fully seated and flush with the surrounding material.

3. PostInstallation:

- After installation, perform a function check to ensure that the extractor is operating correctly.
- Store the firearm in a secure location when not in use.

Disposal Instructions

- When disposing of the AR15A4 Extractor Pin, follow local regulations regarding the disposal of firearm components.
- Do not throw the extractor pin in regular household waste; instead, contact your local waste management authority for proper disposal methods.

Contact Information for Further Support

For any safety inquiries or concerns regarding the AR15A4 Extractor Pin, please refer to the manufacturer's website or customer service resources available in your region.

Thank you for your attention to these safety instructions. Your safety and the safety of others depend on the proper use and handling of this product.

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk