

1911 GOVERNMENT RAIL INNER RECOIL SPRING - COLT 1911 GOVERNMENT RAIL INNER RECOIL SPRING

[Handgun Parts](#) > [Recoil Parts](#) > [Recoil Spring Plugs](#)

FITS: 1911 Government Models

1911 GOVERNMENT RAIL INNER RECOIL SPRING



Attributes

- Name: [COLT 1911 GOVERNMENT RAIL INNER RECOIL SPRING](#)
- Manufacturer: [COLT](#)
- Product no.: 160308242
- Mfr. No.: 300264
- Model: Government
- Weapon type: 1911,Colt
- Delivery weight: 0.005kg
- Shipping height: 6mm
- Shipping width: 6mm
- Shipping length: 140mm

Item details

Made in USA

Table of Contents

- [Startpage](#)
- [Safety Instructions for the 1911 Government Rail Inner Recoil Spring](#)
- [About Us](#)

Safety Instructions for the 1911 Government Rail Inner Recoil Spring

Introduction

Thank you for choosing the 1911 Government Rail Inner Recoil Spring by Colt. This safety instruction guide is designed to ensure the safe use and handling of this product in compliance with the EU General Product Safety Regulation (GPSR). Please read and follow these instructions carefully to ensure your safety and the proper functioning of the product.

General Safety Guidelines

- Always handle the recoil spring with care to avoid personal injury.
- Ensure that the recoil spring is used only in compatible Colt 1911 Government models.
- Store the recoil spring in a safe place, out of reach of children and pets.
- Regularly inspect the recoil spring for signs of wear or damage before use.
- Do not attempt to modify or alter the recoil spring in any way.
- Report any unsafe conditions or incidents to the relevant authorities.

Specific Safety Precautions for Use

- Ensure that the firearm is unloaded before installing or handling the recoil spring.
- Wear appropriate safety gear, including eye protection, when working with firearms.
- Follow the manufacturer's guidelines for installation and usage to prevent malfunctions.
- Keep fingers and other body parts clear of moving parts during installation and operation.
- If you experience any malfunctions, cease use immediately and consult a qualified gunsmith.

Instructions for Installation and Usage

1. Preparation:

- Ensure the firearm is completely unloaded and pointed in a safe direction.
- Gather necessary tools for installation, including a punch tool and a hammer.

2. Installation:

- Remove the old recoil spring from the firearm by following the manufacturer's disassembly instructions.
- Carefully insert the new 1911 Government Rail Inner Recoil Spring into the designated area of the firearm.
- Ensure that the spring is seated properly and securely.

3. Usage:

- After installation, reassemble the firearm according to the manufacturer's guidelines.
- Conduct a function check to ensure that the recoil spring is operating correctly.
- Always adhere to safe handling practices when using the firearm.

4. Maintenance:

- Regularly clean and lubricate the recoil spring as part of your firearm maintenance routine.
- Inspect the recoil spring for wear or damage after every use.

Disposal Instructions

- Dispose of the recoil spring in accordance with local regulations regarding metal recycling.
- Do not dispose of the recoil spring in regular household waste.
- If the recoil spring is damaged or no longer usable, consult local waste management authorities for proper disposal methods.

Contact Information for Further Support

For any safety inquiries or further assistance regarding the 1911 Government Rail Inner Recoil Spring, please consult your local retailer or manufacturer's website.

Thank you for your attention to these safety instructions. Your safety and the safe operation of your firearm are our top priorities.

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk