

LE901-16SE SPRING PIN, 96906_MS16562-105 - COLT LE901-16SE SPRING PIN, 96906_MS16562-105

[Home](#)

FITS: LE901

LE901-16SE SPRING PIN, 96906_MS16562-105



Attributes

- Name: [COLT LE901-16SE SPRING PIN, 96906_MS16562-105](#)
- Manufacturer: [COLT](#)
- Product no.: 160308351
- Mfr. No.: 95215
- Model: LE901
- Weapon type: Colt
- Shipping height: 3mm
- Shipping width: 89mm
- Shipping length: 152mm

Item details

Made in USA

Table of Contents

- [Startpage](#)
- [LE90116SE SPRING PIN Safety Instruction Guide](#)
- [About Us](#)

LE90116SE SPRING PIN Safety Instruction Guide

Introduction

Thank you for choosing the LE90116SE SPRING PIN, 96906_MS16562105. This guide provides essential safety instructions and information to ensure the safe use of this product. Please read this guide carefully to understand how to use the product safely and effectively.

General Safety Guidelines

- Ensure that the product is used only for its intended purpose.
- Keep the product out of reach of children and vulnerable individuals.
- Regularly inspect the product for signs of wear or damage before use.
- Report any unsafe products or accidents to the relevant authorities.
- Stay informed about recalls or safety updates through the EU's Safety Gate platform.

Specific Safety Precautions for Use

- Use appropriate protective gear when handling the spring pin to prevent injury.
- Avoid using the spring pin in environments that exceed its specified limits (temperature, pressure, etc.).
- Never modify the spring pin; alterations may compromise safety and functionality.
- Ensure that the spring pin is compatible with your specific Colt LE901 model before installation.

Instructions for Installation and Usage

1. Preparation:

- Gather all necessary tools and equipment before starting the installation.
- Ensure that the workspace is clean and free from obstructions.

2. Installation:

- Align the spring pin with the designated hole in the Colt LE90116SE.
- Gently insert the spring pin until it is fully seated.
- Ensure that the pin is secure and does not move freely; it should fit snugly in place.

3. Usage:

- After installation, check the functionality of the spring pin by performing a test operation.
- If the spring pin does not function as expected, remove it and inspect for damage or improper installation.

4. PostInstallation Check:

- Regularly check the spring pin for any signs of wear or loosening.
- Replace the spring pin if any damage is detected or if it no longer functions properly.

Disposal Instructions

- Dispose of the spring pin in accordance with local regulations for metal waste.
- Do not dispose of the product in regular household waste.
- If unsure about disposal methods, consult local waste management authorities.

Contact Information for Further Support

For any safety inquiries or concerns regarding the LE90116SE SPRING PIN, please refer to the relevant contact points established within the EU. Ensure that you have the product details at hand when seeking assistance.

By following these guidelines, you can ensure the safe and effective use of the LE90116SE SPRING PIN. Your safety is our priority, and we appreciate your cooperation in adhering to these instructions. Thank you for your attention and safe usage!

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk