

LE901-16SE SPRING PIN, 96906_MS16562-117 - SPRING PIN FOR COLT LE901-16SE

[Home](#)

FITS: LE901

LE901-16SE SPRING PIN, 96906_MS16562-117



Attributes

- Name: [SPRING PIN FOR COLT LE901-16SE](#)
- Manufacturer: [COLT](#)
- Product no.: 160308352
- Mfr. No.: 95214
- Model: LE901
- Weapon type: Colt
- Delivery weight: 0.023kg
- Shipping height: 4mm
- Shipping width: 127mm
- Shipping length: 76mm

Item details

Made in USA

Table of Contents

- [Startpage](#)
- [Safety Instruction Guide for LE90116SE SPRING PIN](#)
- [About Us](#)

Safety Instruction Guide for LE90116SE SPRING PIN

Introduction

Thank you for choosing the LE90116SE SPRING PIN, model 96906_MS16562117. This guide provides essential safety instructions to ensure the safe and effective use of this product. Please read this document carefully before use to understand the safety measures, installation, and disposal instructions.

General Safety Guidelines

- Always use the LE90116SE SPRING PIN in accordance with the manufacturer's instructions.
- Keep this product out of reach of children and vulnerable individuals.
- Inspect the product for any visible damage before use. Do not use if damaged.
- Use appropriate personal protective equipment (PPE) when handling the spring pin.
- Report any unsafe products or incidents to the relevant authorities.

Specific Safety Precautions for Use

- Ensure that the spring pin is compatible with your Colt LE90116SE firearm before installation.
- Avoid using excessive force during installation to prevent injury or damage.
- Never attempt to modify or alter the spring pin, as this may compromise safety.
- Store the spring pin in a dry, cool place when not in use to prevent corrosion.
- If you experience any issues during use, cease operation immediately and consult a qualified professional.

Instructions for Installation and Usage

1. Preparation:

- Ensure that your workspace is clean and welllit.
- Gather all necessary tools for installation.

2. Installation Steps:

- Remove any existing spring pins from the firearm as per the manufacturer's guidelines.
- Align the LE90116SE SPRING PIN with the designated hole on the Colt LE90116SE.
- Gently insert the spring pin, ensuring it is positioned correctly.
- Use a suitable tool to secure the spring pin in place without applying excessive force.

3. Usage:

- After installation, perform a safety check to ensure the spring pin is secure.
- Follow the Colt LE90116SE operational manual for further instructions on the safe use of the firearm.

Disposal Instructions

- Dispose of the LE90116SE SPRING PIN in accordance with local regulations regarding metal waste.
- Do not dispose of the product in household waste.
- Contact your local waste management facility for proper disposal methods.

Contact Information for Further Support

For any inquiries or support regarding the LE90116SE SPRING PIN, please reach out to the manufacturer or authorized dealer. Ensure to have your product details ready for efficient assistance.

Please ensure that you adhere to these safety guidelines to promote safe usage of the LE90116SE SPRING PIN. Your safety is our priority.

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk