

AR15A4 DISCONNECTOR - COLT AR15A4 DISCONNECTOR

[Rifle Parts](#) > [Triggers Parts](#) > [Disconnecter Parts](#) > [Disconnectors](#)

FITS: AR-15 - Common Parts

AR15A4 DISCONNECTOR



Attributes

- Name: [COLT AR15A4 DISCONNECTOR](#)
- Manufacturer: [COLT](#)
- Product no.: 160308417
- Mfr. No.: 63036
- Weapon type: AR-15
- Delivery weight: 0.009kg
- Shipping height: 3mm
- Shipping width: 89mm
- Shipping length: 152mm

Item details

Made in USA

US export classification: 0A501.c

Table of Contents

- [Startpage](#)
- [AR15A4 DISCONNECTOR Safety Instruction Guide](#)
- [About Us](#)

AR15A4 DISCONNECTOR Safety Instruction Guide

Introduction

Thank you for choosing the AR15A4 DISCONNECTOR by COLT. This guide provides important safety instructions and guidelines to ensure the safe use of this product. Please read this manual carefully before installation and usage.

General Safety Guidelines

- Ensure that the product is only used as intended and in accordance with the manufacturer's specifications.
- Keep the product out of reach of children and vulnerable individuals.
- Regularly inspect the product for any signs of damage or wear.
- Always follow local laws and regulations regarding firearm components.
- In case of any product-related incidents, report them to the appropriate authorities.

Specific Safety Precautions for Use

- Always handle the AR15A4 DISCONNECTOR with care during installation and maintenance.
- Ensure that the firearm is unloaded and pointed in a safe direction before beginning any work.
- Wear appropriate safety gear, such as eye protection, when installing or handling the disconnectors.
- Do not modify the disconnectors in any way that could compromise their safety or functionality.
- Be aware of the potential hazards associated with the use of firearm components, including accidental discharge.

Instructions for Installation and Usage

1. Preparation:

- Gather all necessary tools and equipment before starting the installation.
- Ensure that you are in a safe and controlled environment.

2. Installation Steps:

- Remove the upper and lower receivers of the AR15 platform.
- Locate the disconnecter housing within the lower receiver.
- Carefully remove the existing disconnecter if applicable.
- Insert the AR15A4 DISCONNECTOR into the housing, ensuring it is seated properly.
- Reassemble the lower and upper receivers, making sure all components are secure.

3. Usage Guidelines:

- After installation, conduct a function check to ensure proper operation.
- Follow the manufacturer's recommendations for maintenance and care.
- Always be mindful of the firearm's safety features while using the disconnectors.

Disposal Instructions

- Dispose of the AR15A4 DISCONNECTOR responsibly according to local regulations.
- If the product is no longer usable, consider recycling where possible to minimize environmental impact.

Contact Information for Further Support

For any inquiries or concerns regarding the AR15A4 DISCONNECTOR, please refer to the manufacturer's official contact points. Ensure you have relevant product information at hand for efficient support.

By following these guidelines, you can ensure the safe and effective use of your AR15A4 DISCONNECTOR. Thank you for prioritizing safety and compliance with the EU General Product Safety Regulation.

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk