

CZ SHADOW 2 9MM 4.89 BBL 17RD GREY - CZ SHADOW 2 9MM 4.89 BBL 17RD GREY

In recent years, the SP-01 Shadow has taken the competition circuit by storm. In USPSA Production Division, CZ pistols are now used by twice as many top-level competitors than any other maker. Given that popularity, it was high time to up the ante. Starting from scratch, CZUB engineers took the best features of the original Shadow and improved upon them. More than two years later, we're seeing the fruits of their efforts. With a higher beavertail and undercut trigger guard, the shooter's hand is able to be as close to the bore axis as possible. With a contoured slide, the majority of the reciprocating mass is also centered on the bore, equating to less muzzle flip. Increased weight at the dust cover/rail also helps keep the muzzle down. The Shadow 2's swappable mag release has an adjustable, extended button with three settings to allow shooters to set it in the spot most comfortable for them. Best of all, new trigger components give smooth DA and crisp, clean SA while drastically reducing trigger reset. A hardy nitride finish coats the entire pistol, leaving it nearly impervious to corrosion, with an Urban Grey Polycoat on the frame. Thin black aluminum grips have healthy checkering to match the fine front and backstrap checkering of the pistol itself. Sitting atop the slide are a set of target sights — fiber optic on front and a serrated, black HAJO rear (click adjustable for elevation, drift adjustable for windage).



Attributes

- Name: CZ SHADOW 2 9MM 4.89 BBL 17RD GREY
- Manufacturer: CZ USA
- Product no.: 250031376
- Mfr. No.: 91255
- Action Type: Semi-Auto
- Barrel Length: 4.89"
- Capacity: 17-Round
- Finish: NA
- Frame Finish: Šedivá
- Frame Material: Steel
- Front Sight: Fiber Optic
- Length: 8.53"
- Magazine Included: Yes
- Magazine Type: Detachable
- Make: CZ
- Model: Shadow 2
- Muzzle: NA
- Náboje: 9 mm Luger
- Rear Sight: Fiber Optic
- Safety: NA
- Sights: Fiber Optic
- Stock Material: NA
- Weight: 2.90625
- Delivery weight: 2.182kg
- Shipping height: 70mm
- Shipping width: 216mm
- Shipping length: 292mm
- UPC: 806703912554

Item details

US export classification: 0A507.a

Table of Contents

- [Startpage](#)
- [English: CZ SHADOW 2 9MM Safety Instruction Guide](#)
- [Český: Návod k bezpečnému použití CZ SHADOW 2 9MM](#)

CZ SHADOW 2 9MM Safety Instruction Guide

Introduction

Thank you for choosing the CZ SHADOW 2 9MM. This guide provides essential safety instructions to ensure the safe use and handling of your firearm. It is crucial to follow these guidelines to minimize risks and enhance your shooting experience.

General Safety Guidelines

- Always treat every firearm as if it is loaded.
- Keep your firearm pointed in a safe direction at all times.
- Keep your finger off the trigger until you are ready to shoot.
- Be aware of your target and what lies beyond it.
- Store your firearm securely and out of reach of children and unauthorized users.
- Use only the recommended ammunition for your CZ SHADOW 2 9MM.
- Regularly inspect your firearm for any signs of wear or damage.
- Be mindful of local laws and regulations regarding firearm use.

Specific Safety Precautions for Use

- Ensure the firearm is unloaded when not in use.
- Always wear appropriate eye and ear protection when shooting.
- Do not use the firearm under the influence of drugs or alcohol.
- Avoid using the firearm in wet or damp conditions to prevent corrosion.
- Ensure that the magazine is properly inserted before attempting to fire.
- Do not attempt to modify or alter the firearm in any way.
- Familiarize yourself with the operation of the safety mechanisms before use.
- Always use a proper shooting stance to maintain control.

Instructions for Installation and Usage

Installation

- Ensure that the firearm is unloaded before installation.
- Attach any accessories (e.g., sights) according to the manufacturer's instructions.
- Check that all components are securely installed before use.

Usage

- Load the magazine with the appropriate ammunition.
- Insert the magazine into the firearm until it clicks into place.
- Pull the slide back and release it to chamber a round.
- Engage the safety mechanism when not in use.
- To fire, disengage the safety, aim at your target, and gently squeeze the trigger.
- After firing, ensure the firearm is unloaded before cleaning or storing.

Disposal Instructions

- Dispose of any spent cartridges and ammunition responsibly.
- Follow local regulations for the disposal of firearms and ammunition.
- If you need to dispose of the firearm itself, contact a licensed dealer or local authorities for guidance.

Contact Information for Further Support

For any safety inquiries or concerns, please reach out to your local authorized CZ dealer or the manufacturer's support services. Ensure you have the model and serial number of your firearm available for reference.

By following these safety instructions, you can help ensure a safe and enjoyable experience with your CZ SHADOW 2 9MM. Always prioritize safety and responsibility when handling firearms.

Návod k bezpečnému použití CZ SHADOW 2 9MM

Úvod

Děkujeme, že jste si zakoupili CZ SHADOW 2 9MM. Tento dokument obsahuje důležité informace o bezpečném používání a údržbě vaší pistole. Dodržování těchto pokynů vám pomůže zajistit bezpečnost vaši i ostatních.

Obecné bezpečnostní pokyny

- Před použitím si důkladně přečtěte tento návod.
- Ujistěte se, že zbraň je vždy považována za nabitou, dokud není prokazatelně vybitá.
- Nikdy nesměřujte zbraň na nic, co nechcete zničit.
- Používejte pouze doporučené náboje 9 mm Luger.
- Zbraň uchovávejte mimo dosah dětí a nezletilých osob.
- Při používání zbraně používejte ochranné brýle a sluchátka.
- Zbraň pravidelně kontrolujte a udržujte v dobrém stavu.

Specifické bezpečnostní opatření při používání

- Před každým použitím zkontrolujte stav zbraně a ujistěte se, že není poškozená.
- Nikdy se nesnažte upravovat nebo opravovat zbraň, pokud nemáte potřebné znalosti a zkušenosti.
- Při nabíjení a vybíjení zbraně se ujistěte, že je zbraň otočena směrem k bezpečné oblasti.
- Při střelbě se ujistěte, že je za cílem dostatečně bezpečný prostor.
- Pokud dojde k selhání zbraně, nezkoušejte ji okamžitě znovu použít. Nechte ji zkontrolovat odborníkem.

Pokyny pro instalaci a používání

- Před prvním použitím proveďte následující kroky:
 1. Zkontrolujte, zda je zbraň vybitá.
 2. Ujistěte se, že všechny komponenty jsou správně nainstalovány.
 3. Seznamte se s ovládacími prvky zbraně a jejich funkcemi.
- Při používání zbraně:
 - Ujistěte se, že máte pevný úchop na rukojeti a prsty mimo spoušť, dokud nejste připraveni střílet.
 - Použijte nastavitelný uvolňovač zásobníku, aby byl pro vás co nejpohodlnější.
 - Dodržujte doporučené postupy pro údržbu a čištění zbraně, aby byla stále v optimálním stavu.

Pokyny pro likvidaci

- Zbraň a její součásti likvidujte podle místních předpisů o odpadu a nebezpečných materiálech.
- Nepoužívejte zbraň, která je poškozená nebo nefunkční. V takovém případě ji nechte zlikvidovat odborníkem.

Kontaktní informace pro další podporu

Pokud máte jakékoli dotazy nebo potřebujete další informace, obraťte se na autorizovaného prodejce nebo výrobce.