

# DRUM SANDER BANDS #408, 432 - DREMEL #432 BAND

[Gunsmith Tools](#) > [Power Tools & Accessories](#) > [Drum Sanders](#)

## Make The Most Of Your Hand-Held Tool

½" (12.7mm) dia. coarse grit; No. 432, ½" dia. fine grit. Pak of 6.



## Attributes

- Name: [DREMEL #432 BAND](#)
- Manufacturer: [DREMEL](#)
- Product no.: 257400432
- Mfr. No.: 5000432
- Delivery weight: 0.011kg
- Shipping height: 5mm
- Shipping width: 51mm
- Shipping length: 102mm
- UPC: 080596004323

# Table of Contents

- Startpage
- Safety Instructions for DRUM SANDER BANDS #408, 432 DREMEL #432 BAND
- About Us

# **Safety Instructions for DRUM SANDER BANDS #408, 432 DREMEL #432 BAND**

## **Introduction**

Thank you for choosing the DRUM SANDER BANDS #408, 432 DREMEL #432 BAND. These sanding bands are designed for use with Dremel rotary tools and are intended to provide efficient sanding for various materials. To ensure safe and effective use, please read and follow these safety instructions carefully.

## **General Safety Guidelines**

- Always read and understand the product instructions before use.
- Keep the product out of reach of children and vulnerable individuals.
- Inspect the product before each use for any signs of damage or wear.
- Use personal protective equipment (PPE) such as safety goggles and dust masks.
- Ensure that the work area is clean, welllit, and free of hazards.
- Do not use the product in wet or damp conditions.
- Follow all local regulations regarding the disposal of used sanding bands.
- Report any unsafe products or incidents to the relevant authorities.

## **Specific Safety Precautions for Use**

- Use only with compatible Dremel rotary tools.
- Do not exceed the maximum recommended speed for the sanding bands.
- Avoid applying excessive pressure while sanding to prevent overheating.
- Always allow the tool to come to a complete stop before changing bands.
- Do not use the sanding bands for purposes other than intended.
- Keep hands and body parts away from moving parts during operation.
- Be cautious of dust generated during sanding; use appropriate dust extraction when possible.

## **Instructions for Installation and Usage**

### **1. Installation:**

- Ensure the rotary tool is unplugged before installation.
- Slide the sanding band onto the mandrel of the rotary tool.
- Secure the band by tightening the mandrel screw according to the manufacturer's instructions.

### **2. Usage:**

- Plug in the rotary tool and allow it to reach the desired speed.
- Hold the tool firmly with both hands for better control.
- Apply the sanding band to the material gently and evenly.
- Move the tool in a consistent motion to achieve a uniform finish.
- Frequently check the sanding band for wear and replace as necessary.

## **Disposal Instructions**

- Dispose of used sanding bands in accordance with local waste disposal regulations.
- Do not dispose of sanding bands in regular household waste if they contain hazardous materials.
- Consider recycling options if available in your area.

## **Contact Information for Further Support**

For any safety inquiries or further assistance, please refer to the manufacturer's website or contact their customer service.

By adhering to these safety instructions, you can ensure a safer and more effective experience with your DRUM SANDER BANDS #408, 432 DREMEL #432 BAND. Thank you for your attention to these important safety guidelines.

# About Us

## Brownells UK

### **Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories**

Unit 1, Laughing Dog Industrial Estate  
London Road  
Rugby  
Warwickshire  
CV23 9LP

[www.brownells.co.uk](http://www.brownells.co.uk)