

QUICK CHANGE JAW ASSEMBLY FOR CO-AX PRESS - FORSTER PRODUCTS, INC. QUICK CHANGE JAW ASSEMBLY S-LARGE (0.468"-0.562")

[Reloading](#) > [Reloading Presses](#) > [Single Stage Presses](#)

Reloaders who use the Forster Co-Axial reloading press can take advantage of a quick-change system designed to hold shells, thanks to a set of spring-loaded jaws that contact the base of the cannelure. These self-acting jaws automatically close around the cartridge case as the press works, releasing the case once the press has done its work. Forster now offers a Quick-Change Jaw Assembly for its press, which makes swapping out these jaws for different case sizes a breeze. S-Large - holds .468" to .562" rim S-Small - holds .343" to .422" rim LS-Large - holds .531" to .625" rim LS-Small - holds .312" to .375" rim Each Forster Quick-Change Jaw Assembly allows for easy swapping of S or LS shell-holder jaws, allowing users to adjust the shell holders to accommodate cases ranging in size from .312-.625-inch shell rims. This saves an incredible amount of time when switching over to a new caliber, and it also avoids the frustration of losing springs or misplacing a spare set of shell-holder jaws. As an added bonus, with the Forster Quick-Change Jaw Assembly, there's no possibility of installing the jaws in the wrong direction, avoiding the frustration of assembling the wear plate in backwards or having a flipped jaw.



Attributes

- Name: [FORSTER PRODUCTS, INC. QUICK CHANGE JAW ASSEMBLY S-LARGE \(0.468"-0.562"\)](#)
- Manufacturer: [FORSTER PRODUCTS, INC.](#)
- Product no.: 319000049
- Mfr. No.: 028271-201
- Delivery weight: 0.125kg
- Shipping height: 13mm
- Shipping width: 102mm
- Shipping length: 127mm
- UPC: 757253991417

Item details

Made in USA

Table of Contents

- Startpage
- Quick Change Jaw Assembly for CoAx Press Safety Instructions
- About Us

Quick Change Jaw Assembly for CoAx Press Safety Instructions

Introduction

Thank you for choosing the Quick Change Jaw Assembly for your Forster CoAxial reloading press. This guide provides essential safety instructions to ensure safe and effective use of the product. Please read this manual carefully before using the product to understand the safety guidelines, installation instructions, and proper usage.

General Safety Guidelines

- Ensure that you read and understand the entire manual before using the Quick Change Jaw Assembly.
- Always wear appropriate personal protective equipment (PPE), such as safety glasses and gloves, when using the reloading press.
- Keep the work area clean and free from clutter to prevent accidents.
- Store the Quick Change Jaw Assembly in a dry and secure location when not in use.
- Do not use the Quick Change Jaw Assembly for any purpose other than its intended use.
- Be cautious when handling cartridges and components to avoid accidents.
- Do not attempt to modify or alter the Quick Change Jaw Assembly in any way.
- Always check for proper installation before operating the press.
- Ensure that all components are in good working condition to avoid potential hazards.

Specific Safety Precautions for Use

- *Hazard Identification:*
 - Ensure that the Quick Change Jaw Assembly is compatible with your CoAxial press model.
 - Inspect the assembly for any signs of wear or damage before each use.
- *Avoiding Hazards:*
 - Do not exceed the recommended rim sizes for each jaw assembly (SLarge: .468" to .562", SSmall: .343" to .422", LSLarge: .531" to .625", LSSmall: .312" to .375").
 - Ensure that the jaws are securely locked in place before operating the press.
 - Avoid placing fingers or hands near the moving parts of the press during operation.
- *Age Specific Warnings:*
 - This product is intended for adult use only. Keep out of reach of children and vulnerable individuals.

Instructions for Installation and Usage

1. Installation:

- Ensure that the reloading press is unplugged and not in operation.
- Remove the existing jaw assembly from the press by following the manufacturer's instructions.
- Select the appropriate Quick Change Jaw Assembly (S or LS) based on the cartridge size you will be using.
- Align the jaw assembly with the mounting points on the press and secure it in place according to the manufacturer's instructions.
- Doublecheck that the assembly is properly installed and securely fastened.

2. Usage:

- Load the cartridge case into the jaw assembly, ensuring it is seated correctly.
- Operate the press according to the manufacturer's instructions, allowing the springloaded jaws to

- automatically close around the cartridge case.
- After the operation is complete, the jaws will release the cartridge case automatically.
- If you need to switch to a different case size, repeat the installation steps for the appropriate jaw assembly.

Disposal Instructions

- Dispose of any damaged or worn components of the Quick Change Jaw Assembly in accordance with local regulations.
- Do not dispose of the product in regular household waste. Check for local recycling programs that accept metal and plastic components.

Contact Information for Further Support

For any further inquiries or support regarding the Quick Change Jaw Assembly, please refer to the manufacturer's official contact points or website.

By following these safety instructions, you can ensure a safe and efficient reloading experience with your Forster CoAxial press and Quick Change Jaw Assembly. Always prioritize safety and refer to this guide whenever necessary. Thank you for your attention to these important safety measures.

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk