

CED7000 SILICONE SKINS - CED7000 SILICONE SKIN BLUE

[Shooting Accessories](#) > [Range Gear](#) > [Shot Timers](#)

Protect and personalize your CED7000 Shot Timer with custom made Silicone skins that give your timer a rubbery finish. This makes it more comfortable to grip and protects the timer from scratches and damage in case of falls. Available in black and blue.



Attributes

- Name: [CED7000 SILICONE SKIN BLUE](#)
- Manufacturer: [COMPETITIVE EDGE DYNAMICS](#)
- Product no.: 399000018
- Mfr. No.: 100067
- Color: Blue
- Style: Accessories
- Delivery weight: 0.045kg
- Shipping height: 25mm
- Shipping width: 51mm
- Shipping length: 102mm

Table of Contents

- [Startpage](#)
- [CED7000 Silicone Skins Safety Instructions](#)
- [About Us](#)

CED7000 Silicone Skins Safety Instructions

Introduction

Thank you for choosing the CED7000 Silicone Skins. These silicone skins are designed to protect and personalize your CED7000 Shot Timer, providing a comfortable grip and safeguarding against scratches and damage. Please read this safety instruction guide carefully to ensure safe and effective use of the product.

General Safety Guidelines

- Ensure that the CED7000 Shot Timer is powered off before applying or removing the silicone skin.
- Inspect the silicone skin for any damage before use. Do not use if the skin is torn or compromised.
- Keep the silicone skins out of reach of children to prevent choking hazards.
- Avoid exposing the silicone skins to extreme temperatures or direct sunlight for prolonged periods.
- Regularly check for wear and tear, and replace the silicone skin if it shows signs of significant damage.

Specific Safety Precautions for Use

- Do not use the silicone skins as a substitute for proper handling of the CED7000 Shot Timer.
- Ensure that the silicone skin fits securely on the timer to prevent slipping during use.
- Clean the silicone skin regularly with a mild detergent and water to maintain hygiene.
- Avoid using harsh chemicals or abrasive materials to clean the silicone skin, as they may cause damage.
- If allergic reactions occur, discontinue use immediately and seek medical advice.

Instructions for Installation and Usage

Installation

1. **Remove the CED7000 Shot Timer from any protective packaging.**
2. **Align the silicone skin with the timer:**
 - Ensure the openings for buttons and ports are correctly positioned.
3. **Gently stretch the silicone skin over the timer:**
 - Start from one edge and work your way around to ensure a snug fit.
4. **Check the fit:**
 - Ensure all buttons and ports are accessible and that the skin is securely in place.

Usage

- Use the CED7000 Shot Timer as intended, following the manufacturer's instructions.
- Avoid using excessive force on buttons while the silicone skin is on to prevent damage.
- If using in a competitive environment, ensure that the silicone skin does not interfere with the timer's functionality.

Disposal Instructions

- Dispose of the silicone skin responsibly.
- Check local regulations for the proper disposal of silicone products.
- Do not dispose of the silicone skin in regular household waste if local guidelines specify otherwise.

Contact Information for Further Support

For any safety inquiries or further assistance regarding the CED7000 Silicone Skins, please refer to the manufacturer's contact details provided with your product.

By following these safety instructions, you can ensure a safe and enjoyable experience with your CED7000 Silicone Skins. Thank you for your attention to safety, and enjoy using your product!

About Us

Brownells Austria

Brownells - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

www.brownells.at