

LEVER ACTION HRA AXE 410 SHOTGUN 4+1 - LEVER ACTION AXE 410 SHOTGUN 4+1

[Firearms](#) > [Shotguns](#) > [Lever Action](#)

It's fun, for sure, but it also has more practicality than meets the eye. The Axe has the same 5-round capacity of 2 ½" shells as its larger Lever Action .410 Shotgun counterparts, and the addition of a loading gate means that you can keep that capacity topped off at all times without needing to remove a tube magazine. Another practical advantage is its size. With a barrel length of just under 16" and an overall length of just over 26" the Axe can be stored in far more places than your average shotgun. The barrel is topped off with a brass bead front sight and the muzzle end is internally threaded for invector style chokes. A full choke is included right out of the box, and additional chokes are available on [HenryPride.com](#). The "axe handle" pistol grip gives the firearm its name and is engraved on the bottom with the iconic Henry Cowboy logo for that unmistakable touch of Henry class. Speaking of Henry class, the Axe .410 is available in 2 iconic finishes – hardened brass and matte blued steel.



Attributes

- Name: [LEVER ACTION AXE 410 SHOTGUN 4+1](#)
- Manufacturer: [HENRY REPEATING ARMS](#)
- Product no.: 430100064
- Mfr. No.: H018BAH-410
- Action Type: Lever Action
- Barrel Length: 15.14"
- Capacity: 4+1-Round
- Finish: Blued
- Front Sight: Bead
- Gauge: .410 Bore
- Length: 16.4"
- Magazine Included: NA
- Magazine Type: Fixed
- Make: Henry
- Model: Axe
- Muzzle: NA
- Rear Sight: None
- Stock Material: Wood
- Weight: 5.75 lbs
- Delivery weight: 3.057kg
- Shipping height: 51mm
- Shipping width: 171mm
- Shipping length: 718mm
- UPC: 619835500076

Item details

Made in USA

US export classification: 0A502

Table of Contents

- [Startpage](#)
- [Safety Instruction Guide for the LEVER ACTION HRA AXE 410 SHOTGUN 4+1](#)
- [About Us](#)

Safety Instruction Guide for the LEVER ACTION HRA AXE 410 SHOTGUN 4+1

Introduction

Thank you for choosing the LEVER ACTION HRA AXE 410 SHOTGUN 4+1. This guide provides important safety instructions and guidelines to ensure safe and effective use of your shotgun. Please read this manual carefully before using the product.

General Safety Guidelines

- Always treat every firearm as if it is loaded.
- Keep the shotgun pointed in a safe direction at all times.
- Ensure the shotgun is unloaded when not in use.
- Store the shotgun in a secure location, out of reach of children and unauthorized users.
- Use only the appropriate ammunition specified for this shotgun.
- Regularly inspect your shotgun for any signs of wear or damage.
- Do not modify the shotgun in any way that may affect its safety or performance.
- Follow all local laws and regulations regarding firearm ownership and usage.

Specific Safety Precautions for Use

- Always wear appropriate eye and ear protection when shooting.
- Do not shoot at hard surfaces or water, as bullets can ricochet.
- Be aware of your surroundings and ensure a clear line of sight before firing.
- Do not load the shotgun until you are ready to shoot.
- Never rely solely on the safety mechanism; always follow safe handling practices.
- Avoid using the shotgun under the influence of drugs or alcohol.
- Be cautious of others nearby when handling or firing the shotgun.

Instructions for Installation and Usage

1. Loading the Shotgun:

- Ensure the shotgun is pointed in a safe direction.
- Open the loading gate and insert the ammunition into the chamber.
- Close the loading gate securely.
- Check that the shotgun is ready for use.

2. Firing the Shotgun:

- Hold the shotgun firmly with both hands.
- Ensure your finger is off the trigger until you are ready to fire.
- Aim at the target and gently squeeze the trigger to fire.
- After firing, keep the shotgun pointed downrange until you are ready to reload or check the chamber.

3. Unloading the Shotgun:

- Point the shotgun in a safe direction.
- Open the loading gate and remove all ammunition.
- Check the chamber to ensure it is empty.

4. Maintenance:

- Regularly clean your shotgun according to the manufacturer's instructions.
- Store the shotgun in a dry place to prevent corrosion.
- Inspect the shotgun for any signs of damage before each use.

Disposal Instructions

When disposing of the shotgun, follow these guidelines: * Consult local laws regarding the disposal of firearms. * If the shotgun is no longer usable, consider contacting a licensed firearms dealer for safe disposal. * Do not dispose of ammunition in regular trash. Contact local authorities for guidance on proper disposal.

Contact Information for Further Support

For any safety inquiries or concerns regarding the LEVER ACTION HRA AXE 410 SHOTGUN 4+1, please refer to the contact information provided with your purchase.

Conclusion

Your safety is our priority. By following the guidelines and instructions outlined in this manual, you can ensure a safe and enjoyable experience with your LEVER ACTION HRA AXE 410 SHOTGUN 4+1. Always prioritize safety and responsibility when handling firearms.

About Us

Brownells Česká republika

Brownells - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

www.brownells.cz