

FLARED MAGAZINE FLOOR PLATE FOR GLOCK - FORWARD CONTROLS DESIGN GLOCK MAGAZINE FLOOR PLATE, FLARED

[Magazines](#) > [Handgun Magazines](#) > [Magazine Parts](#) > [Magazine Floorplates](#)

MFP-G (Magazine Floor Plate, Glock) is a replacement floor plate/base plate for Glock 9mm and .40 cal double column magazines. Machined from solid 6061 aluminum and hard coat Type III anodized, it is available in either standard or flared versions. MFP-G was designed and made for duty and defense applications. Its lines and shape are dictated by the functions it was designed to perform, its looks are subtle and modest, but for the flutes on the sides and a tastefully small and hard to find Cygnus logo engraved on the bottom, it's difficult to tell it apart from a factory Glock magazine floor plate. There will be no red, white or blue anodized variants of MFP-G. Most Glocks have a semi circular cutout at the rear base of the grip to enable users to manually strip the magazine from the grip/magazine well should it fail to drop free. G17M and G19M also have the semi circular cutout in front of the base of the grip. MFP-G improves on this built-in Glock feature by giving the magazine a front lip a reverse angle that's missing on factory Glock magazine floor plates, the simple and subtle change provides the user with ample surface area and positive grasping space to manually strip/pull the magazine away from the weapon by using the front and back bottom of the magazine. Should the user choose to grasp and pull the magazine from the sides, MFP-G also provides two long and wide flutes along the sides that are essentially coarse serrations. There's no right or wrong way to strip and pull the magazine, MFP-G provides the user the means to do so from accessing the magazine's front and rear, or left and right. Length: 1.833 (MFP-G, Flared). Glock Gen 5 factory magazine floor plate is 1.701 for reference Width: 1.132. Glock Gen 3 factory magazine plate is 1.300. Weight: 0.50oz



Attributes

- Name: [FORWARD CONTROLS DESIGN GLOCK MAGAZINE FLOOR PLATE, FLARED](#)
- Manufacturer: [FORWARD CONTROLS DESIGN](#)
- Product no.: 430103591
- Mfr. No.: MFP, G, FLARED
- Colour: Black
- Weapon type: Glock
- Delivery weight: 0.435kg
- Shipping height: 20mm
- Shipping width: 83mm
- Shipping length: 140mm
- UPC: 688201997499

Item details

Made in USA

Table of Contents

- Startpage
- FLARED MAGAZINE FLOOR PLATE FOR GLOCK SAFETY INSTRUCTIONS
- About Us

FLARED MAGAZINE FLOOR PLATE FOR GLOCK SAFETY INSTRUCTIONS

Introduction

Thank you for choosing the FLARED MAGAZINE FLOOR PLATE FOR GLOCK by FORWARD CONTROLS DESIGN. This product is designed to enhance the functionality of your Glock magazines while ensuring safety during use. Please read this safety instruction guide carefully to understand how to use this product safely and effectively.

General Safety Guidelines

- Always ensure that your firearm is unloaded before installing or handling magazines.
- Keep the magazine floor plate out of reach of children and unauthorized users.
- Inspect the magazine floor plate regularly for any signs of wear or damage.
- Only use the FLARED MAGAZINE FLOOR PLATE with compatible Glock magazines (9mm and .40 cal double column).
- Follow all local laws and regulations regarding firearm accessories.

Specific Safety Precautions for Use

- When removing the magazine from the firearm, ensure that the firearm is pointed in a safe direction.
- Use a firm grip when pulling the magazine to avoid slipping and potential injury.
- Do not attempt to modify the magazine floor plate or any part of the magazine.
- If the magazine does not drop free, do not force it. Instead, follow the proper procedures for manual removal.
- Avoid using excessive force when stripping the magazine from the grip to prevent damage to the magazine or firearm.

Instructions for Installation and Usage

Installation

1. Ensure that the magazine is unloaded and the firearm is pointed in a safe direction.
2. Remove the existing floor plate from the magazine by following the manufacturer's instructions.
3. Align the FLARED MAGAZINE FLOOR PLATE with the magazine base.
4. Press firmly until the floor plate clicks into place.
5. Verify that the floor plate is securely attached before use.

Usage

- To remove the magazine, grasp the front and back bottom of the magazine or use the flutes on the sides for better grip.
- Pull the magazine straight out from the grip, ensuring that the firearm remains pointed in a safe direction.
- If necessary, practice removing the magazine in a controlled environment to become familiar with the process.

Disposal Instructions

- Dispose of the FLARED MAGAZINE FLOOR PLATE in accordance with local regulations.
- Do not dispose of the product in household waste.
- Consider recycling the aluminum material if possible.

Contact Information for Further Support

For further assistance, please refer to the manufacturer's website or customer service.

Thank you for your attention to these safety guidelines. Your safety and the safety of others is our top priority.

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk