

ADJUSTABLE INCLINATION MOUNT - ERATAC ADJUSTABLE INCLINATION MOUNT FOR 36MM SCOPE, LEVER SYSTEM

[Optics & Mounting](#) > [Rings, Mounts & Bases](#) > [Mount Sets](#)

New GEN-2 with lightweight lever or nut system. Up to 7% lighter. Often the range of elevation adjustment of the scope is not the adequate to compensate for the bullet drop at long ranges. This scope mount was developed to offset the missing adjustment range of the scope. The inclination of the scope mount can be adjusted individually in steps of 10 from 0 - 70 MOA. The mount and the rifle scope can remain on the rifle. Self-locking thread inserts ensure permanent and stable seating of both bolted connections. Eratac guarantee 100% repeatability and shot strength. The upper and lower part of the mount are securely connected to each other by a screw running across the hand wheel diagonally. The hinge is designed as a solid tapered joint and ensures play-free seating of the components. NEW: The mount is now also supplied with a dial in mrad/MIL. The inclination can be changed in steps of 5 between 0 - 20 mrad/MIL. A Dozen Reasons for ERATAC Mounts: Machined from solid high-grade aluminum Hard anodized, matte black Made acc. to Mil-Spec. Type III Rust-proof components 100% repeatability Immediate return to zero! Tested up to cal. .50 BMG Available in many heights for different weapons and scopes With or without inclination for long-range shooting Rings with UNIVERSAL interface for attaching various tactical accessories Clamping system manufactured acc. to NATO-STANAG 4694, compatible with Mil-Std. 1913 Locking by either safety levers or hexagonal nuts without losable parts 100% made in Germany



New GEN-2 with lightweight lever or nut system. Up to 7% lighter. Often the range of elevation adjustment of the scope is not the adequate to compensate for the bullet drop at long ranges. This scope mount was developed to offset the missing adjustment range of the scope. The inclination of the scope mount can be adjusted individually in steps of 10 from 0 - 70 MOA. The mount and the rifle scope can remain on the rifle. Self-locking thread inserts ensure permanent and stable seating of both bolted connections. Eratac guarantee 100% repeatability and shot strength. The upper and lower part of the mount are securely connected to each other by a screw running across the hand wheel diagonally. The hinge is designed as a solid tapered joint and ensures play-free seating of the components. NEW: The mount is now also supplied with a dial in mrad/MIL. The inclination can be changed in steps of 5 between 0 - 20 mrad/MIL. A Dozen Reasons for ERATAC Mounts: Machined from solid high-grade aluminum Hard anodized, matte black Made acc. to Mil-Spec. Type III Rust-proof components 100% repeatability Immediate return to zero! Tested up to cal. .50 BMG Available in many heights for different weapons and scopes With or without inclination for long-range shooting Rings with UNIVERSAL interface for attaching various tactical accessories Clamping system manufactured acc. to NATO-STANAG 4694, compatible with Mil-Std. 1913 Locking by either safety levers or hexagonal nuts without losable parts 100% made in Germany

Attributes

- Name: [ERATAC ADJUSTABLE INCLINATION MOUNT FOR 36MM SCOPE, LEVER SYSTEM](#)
- Manufacturer: [ERATAC](#)
- Product no.: 430105686

- Mfr. No.: T4076-0022
- Finish: Black
- Height: 2.24"
- Length: 5.35"
- Scope Tube Diameter: 36mm
- Style: Clamp-On
- Delivery weight: 0.44kg
- Shipping height: 61mm
- Shipping width: 88mm
- Shipping length: 203mm

Table of Contents

- Startpage
- Safety Instruction Guide for ADJUSTABLE INCLINATION MOUNT ERATAC
- About Us

Safety Instruction Guide for ADJUSTABLE INCLINATION MOUNT ERATAC

Introduction

Thank you for choosing the ADJUSTABLE INCLINATION MOUNT ERATAC. This product is designed to enhance your shooting experience by providing adjustable inclination for your 36mm scope. Please read this safety instruction guide carefully to ensure safe and effective use of the product.

General Safety Guidelines

- Ensure that the product is used only as intended and in accordance with the manufacturer's instructions.
- Regularly inspect the mount for any signs of wear or damage before use.
- Keep the product out of reach of children and vulnerable individuals.
- Do not modify the mount in any way; modifications can compromise safety and performance.
- Report any unsafe conditions or incidents to the appropriate authorities.

Specific Safety Precautions for Use

- Always ensure that the mount is securely attached to the rifle before use.
- Avoid using the mount in adverse weather conditions that may affect visibility or stability.
- Ensure that the scope is properly calibrated to avoid misalignment and inaccurate shooting.
- Use appropriate eye and ear protection while using firearms equipped with this mount.
- Be aware of your surroundings and ensure a safe shooting environment before using the product.

Instructions for Installation and Usage

1. Installation:

- Ensure that the rifle is unloaded and safe before beginning installation.
- Select an appropriate mounting location on the rifle for the inclination mount.
- Align the mount with the rifle's mounting points and secure it using the provided screws.
- Tighten the screws evenly to ensure a stable fit. Do not overtighten, as this may damage the mount.
- Adjust the inclination of the scope mount as needed, using the lever or nut system to achieve the desired angle.

2. Usage:

- After installation, check the stability of the mount and scope before firing.
- Adjust the inclination in steps of 10 from 0 to 70 MOA, or in steps of 5 between 0 to 20 mrad/MIL as needed.
- Ensure that the selflocking thread inserts are engaged to maintain a stable connection during use.
- After each use, inspect the mount for any signs of wear or damage.

Disposal Instructions

- Dispose of the product in accordance with local regulations and guidelines.
- Do not dispose of the mount in household waste. Instead, take it to a designated recycling facility if available.
- Ensure that all components are disposed of responsibly to minimize environmental impact.

Contact Information for Further Support

For any inquiries regarding safety or product performance, please refer to the manufacturer's contact information provided with the product.

By following these safety instructions, you can ensure a safe and enjoyable experience with your ADJUSTABLE INCLINATION MOUNT ERATAC. Thank you for your attention to safety.

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk