

E-ZEE TRIMMER - LYMAN 6.5 CREEDMOOR TRIM PILOT

[Reloading](#) > [Case Preparation](#) > [Case Trimming](#) > [Case Trimmers](#)

Lyman Introduces a case trimming system for the reloader interested in economy or preferring to have an individual precision hand system for each caliber. The EZEE TRIM case trimming system allows the user to trim cases by hand or with a power attachment (included) to precise pre-set length. The trimmer comes with a case locking device, cutter, trim-to length pilot, cutterhead and both hand and power trimming adapters. The trimmer works with any standard shell holder including Lyman, redding, RCBS, Hornady and Lee Precision. Assembles in seconds and you are ready to trim cases. The EZEE-TRIM system comes in three practical variations. EZEE TRIM Rifle set- Includes hand trimmer, power adapter, cutter head and 5 most popular caliber pilots (.223, .243, .270, .30-06, .308) EZEE TRIM Handgun Set- Includes hand trimmer, power adapter, cutter head, and 6 most popular handgun caliber pilots (9mm, 38 Special, 357, 40 S&W, 44 Mag, .45ACP) EZEE TRIM Universal Set- Includes hand trimmer, power adapter, and cutter head. Just add the pilot for the caliber you wish to trim.



Attributes

- Name: [LYMAN 6.5 CREEDMOOR TRIM PILOT](#)
- Manufacturer: [LYMAN](#)
- Product no.: 539000073
- Mfr. No.: 7821922
- Cartridge: 6.5 Creedmoor
- Delivery weight: 0.045kg
- Shipping height: 25mm
- Shipping width: 25mm
- Shipping length: 76mm
- UPC: 011516719225

Item details

Made in USA

Table of Contents

- Startpage
- EZEE TRIMMER LYMAN 6.5 CREEDMOOR TRIM PILOT Safety Instructions
- About Us

EZEE TRIMMER LYMAN 6.5 CREEDMOOR TRIM PILOT Safety Instructions

Introduction

Thank you for choosing the EZEE TRIMMER LYMAN 6.5 CREEDMOOR TRIM PILOT. This product is designed to provide an efficient and precise case trimming experience for reloaders. To ensure your safety and the proper functioning of the trimmer, please read and follow these safety instructions carefully.

General Safety Guidelines

- Always read the instruction manual before using the product.
- Keep the trimmer out of reach of children and vulnerable individuals.
- Ensure that the workspace is clean, dry, and free from clutter.
- Use the trimmer only for its intended purpose as described in the manual.
- Inspect the trimmer and all accessories before use for any signs of damage.
- Do not attempt to modify or disassemble the trimmer.
- Always wear appropriate personal protective equipment, such as safety glasses, when using the trimmer.
- Be aware of your surroundings and ensure that no one is in close proximity while operating the trimmer.

Specific Safety Precautions for Use

- **Electrical Safety:** If using the power attachment, ensure that the power source is compatible and that all electrical connections are secure. Do not use in wet conditions.
- **Cutting Hazards:** The cutter is sharp. Handle with care and avoid direct contact with the cutting edge.
- **Trimming Operation:** Always secure the case properly in the trimmer before operating. Never attempt to trim a case that is not properly locked in place.
- **Maintenance:** Regularly clean the trimmer and inspect it for wear and tear. Replace any worn or damaged parts immediately.
- **Storage:** Store the trimmer in a dry place and ensure it is not accessible to children.

Instructions for Installation and Usage

1. Assembling the Trimmer:

- Unpack all components from the box.
- Attach the cutter head to the trimmer body securely.
- Choose the appropriate caliber pilot and insert it into the cutter head.
- If using the power attachment, connect it to the trimmer as per the instructions in the manual.

2. Trimming Cases:

- Ensure the workspace is clear.
- Select the case you wish to trim and inspect it for damage.
- Lock the case into the trimmer using the case locking device.
- If using the hand trimmer, apply steady pressure to trim the case. For power trimming, switch on the power attachment and hold the case securely.
- After trimming, remove the case and check the length. Repeat if necessary.

3. Cleaning and Maintenance:

- After each use, clean the trimmer with a soft cloth to remove debris.
- Lubricate moving parts as recommended in the manual.

- Store all components in a safe and dry location.

Disposal Instructions

- Dispose of the trimmer and its components in accordance with local regulations.
- Do not dispose of electrical components in regular waste. Follow local guidelines for electronic waste disposal.
- If the trimmer is no longer functional, consider recycling parts where possible.

Contact Information for Further Support

- For any safety inquiries or concerns regarding the EZEE TRIMMER LYMAN 6.5 CREEDMOOR TRIM PILOT, please refer to the product packaging or user manual for the appropriate contact information.

By following these safety instructions, you can ensure a safe and effective experience when using the EZEE TRIMMER LYMAN 6.5 CREEDMOOR TRIM PILOT. Thank you for your attention to safety.

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk