

SC100 DECELERATOR RECOIL PAD - PACHMAYR 1.00" LARGE BLACK LEATHER FACE

[Shooting Accessories](#) > [Recoil Parts](#) > [Recoil Pads](#) > [Universal](#)

Black Base Pad

A 752-style pad with Decelerator material to soak up recoil, and a hard insert at the heel to slide smoothly over clothing.



Attributes

- Name: [PACHMAYR 1.00" LARGE BLACK LEATHER FACE](#)
- Manufacturer: [PACHMAYR](#)
- Product no.: 690012159
- Mfr. No.: 03233
- Colour: Black
- Material: Leather
- Size: Large
- Style: Standard
- Thickness: 1
- Delivery weight: 0.159kg
- Shipping height: 41mm
- Shipping width: 69mm
- Shipping length: 221mm
- UPC: 034337032335

Item details

Made in USA

Table of Contents

- Startpage
- SC100 Decelerator Recoil Pad Safety Instructions
- About Us

SC100 Decelerator Recoil Pad Safety Instructions

Introduction

Thank you for choosing the SC100 Decelerator Recoil Pad by Pachmayr. This product is designed to enhance your shooting experience by reducing recoil impact. Please read this safety instruction guide carefully to ensure safe usage and compliance with EU safety regulations.

General Safety Guidelines

- Ensure that the recoil pad is suitable for your firearm model.
- Always inspect the recoil pad for any signs of damage before use.
- Keep the recoil pad out of reach of children and vulnerable individuals.
- Follow all local laws and regulations regarding firearm accessories.
- Use the recoil pad only for its intended purpose.

Specific Safety Precautions for Use

- Do not use the recoil pad if it shows signs of wear or damage.
- Avoid exposing the recoil pad to extreme temperatures or moisture.
- Ensure that the recoil pad is securely attached to the firearm before use.
- Always wear appropriate safety gear, including eye and ear protection, when using firearms.
- If you experience discomfort or pain while using the recoil pad, discontinue use immediately.

Instructions for Installation and Usage

1. Installation:

- Remove any existing recoil pad from your firearm if applicable.
- Clean the surface where the recoil pad will be attached to ensure a secure fit.
- Align the SC100 Decelerator Recoil Pad with the stock of your firearm.
- Securely fasten the recoil pad using the provided screws or attachment method.
- Ensure that the pad is flush against the stock and does not move.

2. Usage:

- Position the firearm comfortably against your shoulder, with the recoil pad in contact with your shoulder.
- Maintain a firm grip on the firearm while aiming and shooting.
- After use, inspect the recoil pad for any signs of damage or wear.

Disposal Instructions

- Dispose of the recoil pad in accordance with local regulations.
- If the recoil pad is damaged beyond use, consider recycling the materials where possible.
- Do not dispose of the recoil pad in regular household waste if it can be recycled.

Contact Information for Further Support

For any inquiries or concerns regarding the SC100 Decelerator Recoil Pad, please refer to the product packaging for contact details.

Thank you for your attention to these safety instructions. Your safety is our priority, and we hope you enjoy using the SC100 Decelerator Recoil Pad.

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk