

# SIG SAUER 320 SLIDE CATCH LEVER SPRING

[Handgun Parts](#) > [Frame Parts](#) > [Slide Catch Parts](#) > [Slide Catches](#)

Sig Sauer factory Slide Catch Lever Spring for the P320.



## Attributes

- Name: [SIG SAUER 320 SLIDE CATCH LEVER SPRING](#)
- Manufacturer: [SIG SAUER, INC.](#)
- Product no.: 732000558
- Mfr. No.: 01300246R
- Caliber: 40/10 mm (.400-.401)
- Make: Sig Sauer
- Model: P320
- Delivery weight: 0.068kg
- Shipping height: 5mm
- Shipping width: 102mm
- Shipping length: 191mm
- UPC: 798681520435

## Item details

Made in USA

# Table of Contents

- Startpage
- SIG SAUER 320 Slide Catch Lever Spring Safety Instruction Guide
- About Us

# SIG SAUER 320 Slide Catch Lever Spring Safety Instruction Guide

## Introduction

Thank you for choosing the SIG SAUER 320 Slide Catch Lever Spring. This guide provides essential safety information and instructions to ensure the safe use and handling of this product. It is important to read and understand this document before using the Slide Catch Lever Spring.

## General Safety Guidelines

- Ensure that the Slide Catch Lever Spring is compatible with your SIG SAUER P320 model.
- Always handle firearms with care and follow standard safety practices.
- Store the Slide Catch Lever Spring in a safe location, out of reach of children and unauthorized users.
- Inspect the Slide Catch Lever Spring for any signs of damage or wear before installation.
- Report any unsafe products or incidents to the appropriate authorities.
- Regularly check for recall updates on the EU's Safety Gate platform.

## Specific Safety Precautions for Use

- Do not use the Slide Catch Lever Spring if it appears damaged or defective.
- Ensure that the firearm is unloaded before performing any maintenance or installation.
- Use only original SIG SAUER parts and accessories to maintain safety and performance.
- Follow all local laws and regulations regarding firearm modifications and repairs.
- Keep hands and other body parts clear of moving parts during installation and operation.

## Instructions for Installation and Usage

### 1. Preparation:

- Ensure the firearm is completely unloaded.
- Gather necessary tools, including a screwdriver and any specific tools recommended by the manufacturer.

### 2. Installation:

- Remove the slide from the firearm according to the manufacturer's instructions.
- Locate the existing Slide Catch Lever Spring.
- Carefully remove the old spring using the appropriate tools.
- Install the new SIG SAUER 320 Slide Catch Lever Spring by aligning it with the designated slots.
- Ensure that the spring is securely in place.

### 3. Final Checks:

- Reassemble the slide onto the firearm.
- Conduct a function check to ensure the Slide Catch Lever operates correctly.
- Store the firearm safely when not in use.

## Disposal Instructions

- Dispose of the old Slide Catch Lever Spring and any packaging materials in accordance with local regulations.
- Do not throw away the spring in regular household waste; check for local recycling programs or

hazardous waste disposal options.

## Contact Information for Further Support

For any questions or concerns regarding the SIG SAUER 320 Slide Catch Lever Spring, please refer to the manufacturer's website or contact their customer support for assistance.

By following these guidelines, you can ensure the safe and effective use of your SIG SAUER 320 Slide Catch Lever Spring. Always prioritize safety and compliance with all relevant regulations.

# About Us

## **Brownells Česká republika**

**Brownells - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories**

[www.brownells.cz](http://www.brownells.cz)