

DECAP ROD ASSEMBLIES - DECAP ROD ASSEMBLY - 22 REMINGTON JET

[Reloading](#) > [Reloading Dies](#) > [Replacement Parts & Upgrades](#)

Includes decapping pin and expander ball Replacement decap rod assembly for Redding sizing dies.



Attributes

- Name: [DECAP ROD ASSEMBLY - 22 REMINGTON JET](#)
- Manufacturer: [REDDING](#)
- Product no.: 749002279
- Mfr. No.: 32221
- Delivery weight: 0.041kg
- Shipping height: 1mm
- Shipping width: 83mm
- Shipping length: 152mm

Item details

Made in USA

Table of Contents

- Startpage
- DECAP ROD ASSEMBLIES Safety Instruction Guide
- About Us

DECAP ROD ASSEMBLIES Safety Instruction Guide

Introduction

Thank you for choosing the DECAP ROD ASSEMBLY 22 REMINGTON JET by REDDING. This guide provides important safety information, installation instructions, and usage tips to ensure your safety and the effective use of the product. Please read this guide carefully before using the product.

General Safety Guidelines

- Always use the product in accordance with the manufacturer's instructions.
- Keep the product out of reach of children and vulnerable individuals.
- Inspect the product before use for any signs of damage or wear.
- Do not use the product if it appears damaged or defective.
- Report any unsafe conditions or accidents to the appropriate authorities.
- Stay informed about product recalls and safety updates by checking the EU Safety Gate platform.

Specific Safety Precautions for Use

- Ensure you are using the product in a wellventilated area to avoid inhalation of any dust or debris.
- Wear appropriate personal protective equipment (PPE) such as safety glasses and gloves while using the product.
- Avoid using excessive force during installation or operation to prevent injury or damage to the product.
- Keep hands and other body parts away from moving components while the product is in use.
- Do not modify the product in any way as it may result in unsafe conditions.

Instructions for Installation and Usage

1. Installation:

- Unpack the DECAP ROD ASSEMBLY carefully and ensure all parts are present.
- Identify the decapping pin and expander ball included with the assembly.
- Follow the specific instructions provided in your Redding sizing die manual for installing the decap rod assembly.
- Ensure the assembly is securely fitted before proceeding to use.

2. Usage:

- Use the DECAP ROD ASSEMBLY only with compatible Redding sizing dies.
- When decapping, ensure the cartridge case is properly positioned within the die.
- Operate the press smoothly to allow for effective decapping without excessive force.
- After use, clean the decap rod assembly to remove any residue or debris.

Disposal Instructions

- Dispose of the product in accordance with local regulations regarding electronic and mechanical waste.
- Do not dispose of the product in household waste.
- Consider recycling the components where possible to minimize environmental impact.

Contact Information for Further Support

For any inquiries regarding safety or product support, please refer to the manufacturer's website or contact their customer service.

By following these safety instructions, you can ensure a safe and effective experience with the DECAP ROD ASSEMBLY 22 REMINGTON JET. Thank you for prioritizing safety and compliance with the EU General Product Safety Regulation.

About Us

Brownells Austria

Brownells - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

www.brownells.at