

# DECAP ROD ASSEMBLIES - Decap Rod Assembly

[Reloading](#) > [Reloading Dies](#) > [Replacement Parts & Upgrades](#)

Includes decapping pin and expander ball Replacement decap rod assembly for Redding sizing dies.



## Attributes

- Name: [Decap Rod Assembly](#)
- Manufacturer: [REDDING](#)
- Product no.: 749002280
- Mfr. No.: 32242
- Diameter (in): -
- Náboje: 243 WSSM (Winchester Super Short Mag), 6 mm Rem BR (Benchrest)
- Delivery weight: 0.041kg
- Shipping height: 1mm
- Shipping width: 89mm
- Shipping length: 146mm
- UPC: 611760322426

## Item details

Made in USA

# Table of Contents

- Startpage
- DECAP ROD ASSEMBLIES Safety Instruction Guide
- About Us

# DECAP ROD ASSEMBLIES Safety Instruction Guide

## Introduction

Thank you for choosing the DECAP ROD ASSEMBLIES, a replacement decap rod assembly designed for Redding sizing dies. This guide provides essential safety instructions and information to ensure the safe use and handling of this product. Please read this guide carefully before use.

## General Safety Guidelines

- Ensure the product is used only for its intended purpose as described in this manual.
- Always follow the installation and usage instructions to avoid potential hazards.
- Keep the product out of reach of children and vulnerable individuals.
- Regularly check for any signs of wear or damage to the product.
- In case of any malfunction or damage, discontinue use immediately and seek assistance.

## Specific Safety Precautions for Use

- Always wear appropriate personal protective equipment (PPE) such as safety glasses when handling or using the decap rod assembly.
- Ensure that the decap rod assembly is securely attached to the sizing die before use.
- Do not exceed the recommended cartridge specifications to prevent accidents.
- Avoid using the product in wet or damp conditions to reduce the risk of electrical hazards.
- Be cautious of sharp edges when handling the decap rod assembly to prevent cuts or injuries.

## Instructions for Installation and Usage

### 1. Installation:

- Remove the existing decap rod assembly from the sizing die.
- Carefully insert the new decap rod assembly into the die, ensuring it is aligned properly.
- Secure the assembly in place according to the manufacturer's instructions.
- Check that the decap pin and expander ball are correctly positioned before use.

### 2. Usage:

- Use the decap rod assembly exclusively with compatible cartridges:
  - 243 WSSM (Winchester Super Short Mag)
  - 6 mm Rem BR (Benchrest)
- Follow the specific reloading procedures for your chosen cartridge to ensure safe operation.
- Monitor the operation closely for any unusual sounds or resistance during use.

## Disposal Instructions

- Dispose of the decap rod assembly in accordance with local regulations for hazardous materials.
- Do not discard in regular household waste.
- If the product is damaged or no longer usable, consider recycling options where available.

## Contact Information for Further Support

For any questions or concerns regarding the DECAP ROD ASSEMBLIES, please consult your retailer or the manufacturer's official support channels for assistance.

## Conclusion

By following these safety instructions, you can ensure a safe and effective experience with the DECAP ROD ASSEMBLIES. Always prioritize safety and adhere to the guidelines provided in this manual. Thank you for your attention and safe reloading practices!

# About Us

## **Brownells Česká republika**

**Brownells - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories**

[www.brownells.cz](http://www.brownells.cz)