

DECAP ROD ASSEMBLIES - REDDING DECAP ROD ASSEMBLY

[Reloading](#) > [Reloading Dies](#) > [Replacement Parts & Upgrades](#)

Includes decapping pin and expander ball Replacement decap rod assembly for Redding sizing dies.



Attributes

- Name: [REDDING DECAP ROD ASSEMBLY](#)
- Manufacturer: [REDDING](#)
- Product no.: 749002307
- Mfr. No.: 25307
- Cartridge: 300 H&H Magnum,300 Remington Ultra Magnum,300 Weatherby Magnum,300 Winchester Magnum,30-378 Weatherby Magnum,308 Norma Mag
- Diameter (in): -
- Delivery weight: 0.054kg
- Shipping height: 1mm
- Shipping width: 89mm
- Shipping length: 152mm
- UPC: 611760253072

Item details

Made in USA

Table of Contents

- Startpage
- Safety Instruction Guide for DECAP ROD ASSEMBLIES REDDING DECAP ROD ASSEMBLY
- About Us

Safety Instruction Guide for DECAP ROD ASSEMBLIES REDDING DECAP ROD ASSEMBLY

Introduction

Thank you for choosing the DECAP ROD ASSEMBLIES REDDING DECAP ROD ASSEMBLY. This product is designed to provide reliable performance in conjunction with Redding sizing dies. To ensure your safety and the effective use of this product, please read this safety instruction guide carefully.

General Safety Guidelines

- Ensure the product is used in accordance with the manufacturer's instructions.
- Always inspect the decap rod assembly for any signs of wear or damage before use.
- Keep the product out of reach of children and vulnerable individuals.
- Report any unsafe conditions or accidents related to this product to the appropriate authorities.
- Stay informed about any recall notices or safety updates through the EU's Safety Gate platform.

Specific Safety Precautions for Use

- Do not use the decap rod assembly if it appears damaged or defective.
- Wear appropriate personal protective equipment (PPE), such as safety glasses, when using this product.
- Ensure that your workspace is clean and free from obstructions to avoid accidents.
- Only use the decap rod assembly with compatible Redding sizing dies as specified in the product information.
- Avoid using excessive force during installation or operation to prevent injury or damage to the product.

Instructions for Installation and Usage

1. Installation

- Begin by ensuring that the sizing die is properly secured in your reloading press.
- Remove the old decap rod assembly if applicable.
- Insert the new DECAP ROD ASSEMBLY into the sizing die, ensuring it is seated correctly.
- Tighten any necessary screws or fasteners to secure the assembly in place.

2. Usage

- Before starting the reloading process, doublecheck that all components are securely attached.
- Follow the reloading procedures as outlined in your Redding sizing die manual.
- Monitor the performance of the decap rod assembly during use, and stop immediately if you notice any irregularities.

Disposal Instructions

- Dispose of the product in accordance with local regulations for hazardous materials if applicable.
- Do not dispose of the product in regular household waste if it contains any hazardous components.
- Consider recycling options for materials where possible.

Contact Information for Further Support

For any questions or concerns regarding the DECAP ROD ASSEMBLIES REDDING DECAP ROD ASSEMBLY, please refer to the manufacturer's contact information provided with your product or visit the manufacturer's website.

By following the guidelines and instructions provided in this document, you can ensure safe and effective use of your DECAP ROD ASSEMBLIES REDDING DECAP ROD ASSEMBLY. Thank you for your attention to these important safety instructions.

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk