

# DECAP ROD ASSEMBLIES - REDDING DECAP ASSEMBLY

[Reloading](#) > [Reloading Dies](#) > [Replacement Parts & Upgrades](#)

Includes decapping pin and expander ball Replacement decap rod assembly for Redding sizing dies.



## Attributes

- Name: [REDDING DECAP ASSEMBLY](#)
- Manufacturer: [REDDING](#)
- Product no.: 749002410
- Mfr. No.: 33223
- Cartridge: 219 Donaldson Wasp,219 Zipper,22-250 Remington,22-250 Remington Imp 40,223 Remington,224 Weatherby Magnum,225 Winchester,222 Remington Mag,223 Rem Imp 40
- Diameter (in): -
- Delivery weight: 0.045kg
- Shipping width: 83mm
- Shipping length: 146mm
- UPC: 611760332234

## Item details

Made in USA

# Table of Contents

- Startpage
- Safety Instruction Guide for DECAP ROD ASSEMBLIES REDDING DECAP ASSEMBLY
- About Us

# Safety Instruction Guide for DECAP ROD ASSEMBLIES REDDING DECAP ASSEMBLY

## Introduction

Thank you for choosing the DECAP ROD ASSEMBLIES REDDING DECAP ASSEMBLY. This product is designed to provide reliable performance when used with Redding sizing dies. To ensure safe and effective use, please carefully read and follow the safety instructions outlined in this guide.

## General Safety Guidelines

- Ensure that the product is used only for its intended purpose as described in this guide.
- Always inspect the decap rod assembly for any signs of damage before use.
- Keep the product out of reach of children and vulnerable individuals.
- Follow all local regulations regarding the use and disposal of reloading components.
- If you experience any issues or concerns while using the product, discontinue use immediately and seek assistance.

## Specific Safety Precautions for Use

- Always wear appropriate personal protective equipment (PPE), such as safety glasses, when using this product.
- Ensure that your workspace is clean and free from distractions to prevent accidents.
- Use only compatible cartridges as specified:
  - 223 Remington
  - 22250 Remington
  - 219 Zipper
  - 222 Remington Mag
  - 225 Winchester
  - 224 Weatherby Magnum
  - 219 Donaldson Wasp
  - 22250 Remington Imp 40
  - 223 Rem Imp 40
- Do not attempt to modify or alter the decap rod assembly in any way.
- Always follow the manufacturer's instructions for the operation of your reloading equipment.

## Instructions for Installation and Usage

### 1. Installation:

- Ensure that your reloading die is securely mounted in your reloading press.
- Remove any existing decap rod assembly from the die.
- Insert the new DECAP ROD ASSEMBLY into the die, ensuring that it is properly seated.
- Tighten any necessary screws or fasteners to secure the assembly in place.

### 2. Usage:

- Place the cartridge to be decapped in the die.
- Operate the reloading press according to the manufacturer's instructions to decap the cartridge.
- After use, inspect the decap rod assembly for any signs of wear or damage.

## Disposal Instructions

- Dispose of any damaged or worn components in accordance with local waste disposal regulations.
- Do not dispose of the product in regular household waste. Check for local recycling programs or hazardous waste disposal options.

## Contact Information for Further Support

For any inquiries or concerns regarding the DECAP ROD ASSEMBLIES REDDING DECAP ASSEMBLY, please consult the manufacturer's website or customer service for assistance.

## Conclusion

By following these safety instructions, you can ensure a safe and effective experience with your DECAP ROD ASSEMBLIES REDDING DECAP ASSEMBLY. Always prioritize safety and compliance with local regulations when using reloading equipment. Thank you for your attention to these important guidelines.

# About Us

## Brownells UK

### **Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories**

Unit 1, Laughing Dog Industrial Estate  
London Road  
Rugby  
Warwickshire  
CV23 9LP

[www.brownells.co.uk](http://www.brownells.co.uk)