

LOCK-N-LOAD PISTOL METERING INSERTS - HORNADY LOCK-N-LOAD PISTOL ROTOR AND METERING INSERT

[Reloading](#) > [Powder Handling](#) > [Measure Stands & Accessories](#)

For use in your L-N-L Powder Measure, this pistol rotor features a smaller chamber for more precise metering of charge weights between .5 and 17 gr. For extremely precise measurements, the Micrometer Pistol Insert allows you to make and monitor incremental changes and return to previous settings. In order to use this insert, you must have the Pistol Rotor and Standard Metering Insert.



Attributes

- Name: [HORNADY LOCK-N-LOAD PISTOL ROTOR AND METERING INSERT](#)
- Manufacturer: [HORNADY](#)
- Product no.: 749004498
- Mfr. No.: 050128
- Delivery weight: 0.612kg
- Shipping height: 58mm
- Shipping width: 86mm
- Shipping length: 119mm
- UPC: 090255501285

Item details

Made in USA

Table of Contents

- Startpage
- LOCKNLOAD PISTOL METERING INSERTS SAFETY INSTRUCTIONS
- About Us

LOCKNLOAD PISTOL METERING INSERTS SAFETY INSTRUCTIONS

Introduction

Thank you for choosing the LOCKNLOAD PISTOL METERING INSERTS by Hornady. This product is designed for use with your LNL Powder Measure to ensure precise metering of charge weights. Please read this safety instruction guide carefully to ensure safe and effective use of the product.

General Safety Guidelines

- Always use the product in accordance with the manufacturer's instructions.
- Ensure that the product is used only by individuals who are familiar with its operation and safety procedures.
- Keep the product out of reach of children and unauthorized users.
- Regularly inspect the product for any signs of wear or damage. Do not use if damaged.
- Report any unsafe products or incidents to the appropriate authorities.
- Stay informed about product recalls and safety updates via the EU Safety Gate platform.

Specific Safety Precautions for Use

- Use the product only with the compatible Pistol Rotor and Standard Metering Insert.
- Avoid exceeding the recommended charge weight limits (between 0.5 and 17 gr).
- Make incremental changes carefully when using the Micrometer Pistol Insert to ensure accuracy.
- Always wear appropriate safety gear, such as safety glasses, when operating the product.
- Do not attempt to modify or alter the product in any way.
- Ensure that your workspace is clean and free of distractions while using the product.

Instructions for Installation and Usage

1. Preparation

- Ensure you have the Pistol Rotor and Standard Metering Insert.
- Gather all necessary tools and materials before starting.

2. Installation

- Carefully remove the existing metering insert from the Pistol Rotor.
- Align the LOCKNLOAD PISTOL METERING INSERT with the rotor and push it firmly into place until it clicks.
- Ensure that the insert is securely attached and does not wobble.

3. Usage

- Set your desired charge weight using the Micrometer Pistol Insert.
- Make incremental adjustments as needed, and always return to previous settings if required.
- Monitor the charge weight closely during use to ensure accuracy.
- After use, clean the insert and rotor to maintain optimal performance.

Disposal Instructions

- Dispose of the product in accordance with local regulations.
- Do not dispose of the product in household waste.

- If the product is damaged or no longer usable, contact your local waste management facility for proper disposal methods.

Contact Information for Further Support

For any questions or concerns regarding the LOCKNLOAD PISTOL METERING INSERTS, please refer to the manufacturer's contact information provided in the product packaging or user manual.

By following these safety instructions, you can ensure a safe and effective experience with your LOCKNLOAD PISTOL METERING INSERTS. Thank you for your attention to these important safety guidelines.

About Us

Brownells Česká republika

Brownells - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

www.brownells.cz