

# MINI THIRTY® 10-RD MAGAZINE BLUED

Blued steel, 10-Round, 7.62x39mm caliber magazine for Ruger® Mini Thirty® rifles.



## Attributes

- Name: MINI THIRTY® 10-RD MAGAZINE BLUED
- Manufacturer: RUGER
- Product no.: 780001406
- Mfr. No.: 90485
- Capacity: 10-Round
- Finish: Black
- Make: Ruger
- Material: Blued Steel
- Model: Mini-30
- Náboje: 7.62 x 39 mm
- Delivery weight: 0.15kg
- Shipping height: 25mm
- Shipping width: 102mm
- Shipping length: 178mm
- UPC: 736676904853

## Item details

Made in USA

US export classification: 0A501.x

# Table of Contents

- [Startpage](#)
- [English: MINI THIRTY® 10RD MAGAZINE Safety Instruction Guide](#)
- [Český: Návod k bezpečnému používání zásobníku MINI THIRTY® 10RD MAGAZINE RUGER MINI THIRTY](#)

# MINI THIRTY® 10RD MAGAZINE Safety Instruction Guide

## Introduction

Thank you for choosing the MINI THIRTY® 10RD MAGAZINE. This guide provides essential safety instructions and guidelines to ensure the safe use and handling of your magazine. It is important to read and understand this information before using the product.

## General Safety Guidelines

- Ensure that the magazine is used only with Ruger® Mini Thirty® rifles and the specified 7.62x39mm caliber.
- Always handle magazines with care to prevent accidental discharge.
- Store the magazine in a secure location, away from children and unauthorized users.
- Regularly inspect the magazine for any signs of damage or wear before use.
- Follow all local laws and regulations regarding the use and storage of firearms and ammunition.

## Specific Safety Precautions for Use

- Always treat every magazine as if it is loaded.
- Keep your finger off the trigger until you are ready to shoot.
- Never point the firearm or magazine at anything you do not intend to shoot.
- Use only the recommended ammunition (7.62x39mm) for this magazine.
- In case of a malfunction, follow the manufacturer's instructions for clearing the issue safely.
- Do not attempt to modify or disassemble the magazine.

## Instructions for Installation and Usage

### 1. Installation:

- Ensure the firearm is pointed in a safe direction.
- Check that the firearm is unloaded.
- Align the magazine with the magazine well of the Ruger® Mini Thirty® rifle.
- Push the magazine firmly into the magazine well until it clicks into place.

### 2. Usage:

- Load the magazine with 7.62x39mm cartridges, ensuring they are seated properly.
- Insert the loaded magazine into the firearm as described in the installation section.
- Always ensure the firearm is pointed in a safe direction when loading or unloading.
- When finished using the magazine, remove it from the firearm by pressing the magazine release button and pulling the magazine out.

## Disposal Instructions

- Dispose of the magazine in accordance with local laws and regulations.
- If the magazine is damaged or no longer usable, do not attempt to repair it.
- Contact local waste management authorities for guidance on proper disposal methods.

## **Contact Information for Further Support**

For any questions or concerns regarding the MINI THIRTY® 10RD MAGAZINE, please refer to the manufacturer's website or contact their customer support. It is essential to have access to reliable information for safe handling and usage.

## **Conclusion**

By following the guidelines and instructions provided in this safety instruction guide, you can ensure a safe and enjoyable experience with your MINI THIRTY® 10RD MAGAZINE. Always prioritize safety and be responsible in your use and storage of firearms and ammunition.

# Návod k bezpečnému používání zásobníku MINI THIRTY® 10RD MAGAZINE RUGER MINI THIRTY

## Úvod

Tento dokument obsahuje důležité bezpečnostní pokyny pro používání zásobníku MINI THIRTY® 10RD MAGAZINE RUGER MINI THIRTY. Je nezbytné dodržovat tyto pokyny, abyste zajistili bezpečné a efektivní používání produktu.

## Obecné bezpečnostní pokyny

- Zásobník je určen pouze pro pušky Ruger® Mini Thirty® a nesmí být používán s jinými zbraněmi.
- Před použitím zásobníku se ujistěte, že je zbraň vypnutá a odjištěná.
- Nikdy nesmějte mířit na lidi nebo zvířata, a to ani při manipulaci se zásobníkem.
- Udržujte zásobník mimo dosah dětí a zranitelných osob.
- Pokud si nejste jisti, jak správně používat zásobník, vyhledejte odbornou pomoc.

## Specifické bezpečnostní opatření pro použití

- Před každým použitím zkontrolujte, zda je zásobník nepoškozený a čistý.
- Používejte pouze doporučené náboje 7,62 x 39 mm.
- Zásobník naplňte pouze na maximální kapacitu 10 ran.
- Při manipulaci se zásobníkem noste ochranné brýle a chrániče sluchu.
- Nikdy nezapomínejte na základní pravidla bezpečnosti při manipulaci se zbraněmi.

## Pokyny pro instalaci a používání

### • Instalace zásobníku:

1. Ujistěte se, že je puška vypnutá.
2. Držte zásobník v jedné ruce a druhou rukou otevřete zbraň.
3. Vložte zásobník do slotu na zbrani, dokud neuslyšíte cvaknutí.

### • Použití zásobníku:

1. Ujistěte se, že je zásobník správně nainstalován.
2. Naplňte zásobník doporučenými náboji.
3. Před výstřelem zkontrolujte, zda je zbraň odjištěná a připravená k použití.
4. Po dokončení střelby vyjměte zásobník a zkontrolujte, zda je prázdný.

## Pokyny pro likvidaci

- Zásobník a jeho komponenty likvidujte v souladu s místními předpisy o odpadech.
- Nevyhazujte zásobník do běžného odpadu; obraťte se na specializované zařízení na sběr nebezpečných odpadů.
- Pokud je zásobník poškozený nebo nefunkční, informujte se o možnosti jeho ekologické likvidace.

## Kontaktní informace pro další podporu

Pro další dotazy nebo obavy ohledně bezpečnosti produktu se obraťte na příslušného výrobce nebo prodejce. Všechny produkty musí mít kontakt pro bezpečnostní dotazy v rámci EU.

## **Závěr**

Dodržování těchto bezpečnostních pokynů je klíčové pro bezpečné používání zásobníku MINI THIRTY® 10RD MAGAZINE RUGER MINI THIRTY. Ujistěte se, že jste si přečetli a porozuměli všem pokynům před použitím produktu. Bezpečnost by měla být vždy na prvním místě.