

MINI THIRTY® 10-RD MAGAZINE BLUED

[Magazines](#) > [Rifle Magazines](#) > [Magazines](#)

Blued steel, 10-Round, 7.62x39mm caliber magazine for Ruger® Mini Thirty® rifles.



Attributes

- Name: [MINI THIRTY® 10-RD MAGAZINE BLUED](#)
- Manufacturer: [RUGER](#)
- Product no.: 780001406
- Mfr. No.: 90485
- Capacity: 10-Round
- Finish: Black
- Make: Ruger
- Material: Blued Steel
- Model: Mini-30
- Náboje: 7.62 x 39 mm
- Delivery weight: 0.15kg
- Shipping height: 25mm
- Shipping width: 102mm
- Shipping length: 178mm
- UPC: 736676904853

Item details

Made in USA

US export classification: 0A501.x

Table of Contents

- [Startpage](#)
- [MINI THIRTY® 10RD MAGAZINE Safety Instruction Guide](#)
- [About Us](#)

MINI THIRTY® 10RD MAGAZINE Safety Instruction Guide

Introduction

Thank you for choosing the MINI THIRTY® 10RD MAGAZINE. This guide provides essential safety instructions and guidelines to ensure the safe use and handling of your magazine. It is important to read and understand this information before using the product.

General Safety Guidelines

- Ensure that the magazine is used only with Ruger® Mini Thirty® rifles and the specified 7.62x39mm caliber.
- Always handle magazines with care to prevent accidental discharge.
- Store the magazine in a secure location, away from children and unauthorized users.
- Regularly inspect the magazine for any signs of damage or wear before use.
- Follow all local laws and regulations regarding the use and storage of firearms and ammunition.

Specific Safety Precautions for Use

- Always treat every magazine as if it is loaded.
- Keep your finger off the trigger until you are ready to shoot.
- Never point the firearm or magazine at anything you do not intend to shoot.
- Use only the recommended ammunition (7.62x39mm) for this magazine.
- In case of a malfunction, follow the manufacturer's instructions for clearing the issue safely.
- Do not attempt to modify or disassemble the magazine.

Instructions for Installation and Usage

1. Installation:

- Ensure the firearm is pointed in a safe direction.
- Check that the firearm is unloaded.
- Align the magazine with the magazine well of the Ruger® Mini Thirty® rifle.
- Push the magazine firmly into the magazine well until it clicks into place.

2. Usage:

- Load the magazine with 7.62x39mm cartridges, ensuring they are seated properly.
- Insert the loaded magazine into the firearm as described in the installation section.
- Always ensure the firearm is pointed in a safe direction when loading or unloading.
- When finished using the magazine, remove it from the firearm by pressing the magazine release button and pulling the magazine out.

Disposal Instructions

- Dispose of the magazine in accordance with local laws and regulations.
- If the magazine is damaged or no longer usable, do not attempt to repair it.
- Contact local waste management authorities for guidance on proper disposal methods.

Contact Information for Further Support

For any questions or concerns regarding the MINI THIRTY® 10RD MAGAZINE, please refer to the manufacturer's website or contact their customer support. It is essential to have access to reliable information for safe handling and usage.

Conclusion

By following the guidelines and instructions provided in this safety instruction guide, you can ensure a safe and enjoyable experience with your MINI THIRTY® 10RD MAGAZINE. Always prioritize safety and be responsible in your use and storage of firearms and ammunition.

About Us

Brownells Česká republika

Brownells - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

www.brownells.cz