

EJECTOR SPRING - SAVAGE EJECTOR SPRING

[Rifle Parts](#) > [Bolt Parts](#) > [Ejector Parts](#) > [Ejector Springs](#)

FITS: 110/111/112/112BT Top Loading

EJECTOR SPRING



Attributes

- Name: [SAVAGE EJECTOR SPRING](#)
- Manufacturer: [SAVAGE](#)
- Product no.: 855000017
- Mfr. No.: 108187
- Model: 110,111,112
- Weapon type: Savage Arms
- Delivery weight: 0.005kg
- Shipping width: 83mm
- Shipping length: 146mm

Item details

Made in USA

Table of Contents

- [Startpage](#)
- [EJECTOR SPRING SAFETY INSTRUCTIONS](#)
- [About Us](#)

EJECTOR SPRING SAFETY INSTRUCTIONS

Introduction

Thank you for choosing the EJECTOR SPRING for your Savage Arms firearm models 110, 112, and 111. This guide provides important safety instructions to ensure the safe use and handling of your product in compliance with the EU General Product Safety Regulation (GPSR). Please read this guide carefully before installation and use.

General Safety Guidelines

- Ensure the EJECTOR SPRING is compatible with your specific firearm model (Savage Arms 110, 112, or 111).
- Always handle firearms with care and follow all safety protocols.
- Store the EJECTOR SPRING in a safe place, away from children and unauthorized users.
- Regularly inspect the EJECTOR SPRING for any signs of wear or damage before use.
- Do not modify the EJECTOR SPRING or use it in a manner not intended by the manufacturer.
- Report any unsafe products or incidents to the relevant authorities.

Specific Safety Precautions for Use

- Always wear appropriate eye protection while handling or working with firearms.
- Ensure the firearm is unloaded before installing or replacing the EJECTOR SPRING.
- Keep your hands and face clear of the ejection port during operation.
- Use only manufacturer-approved parts to ensure safety and reliability.
- Be aware of your surroundings and ensure that no one is in the line of fire.

Instructions for Installation and Usage

1. Preparation

- Gather the necessary tools for installation, including a screwdriver and any other required equipment.
- Ensure you are in a welllit and safe environment.

2. Installation Steps

- Make sure the firearm is completely unloaded.
- Remove the bolt from the firearm according to the manufacturer's instructions.
- Locate the EJECTOR SPRING assembly within the bolt mechanism.
- Carefully remove the old EJECTOR SPRING if applicable.
- Install the new EJECTOR SPRING by aligning it properly within the assembly.
- Reassemble the bolt according to the manufacturer's specifications.

3. Usage Instructions

- After installation, perform a function check to ensure the EJECTOR SPRING operates correctly.
- Follow the firearm's operating manual for instructions on safe handling and operation.

Disposal Instructions

- Dispose of the EJECTOR SPRING and any packaging materials in accordance with local regulations.
- Do not dispose of the EJECTOR SPRING in regular household waste if it is damaged or deemed unsafe.

Contact Information for Further Support

For any questions or concerns regarding the EJECTOR SPRING, please consult the relevant manufacturer support resources or your local firearm dealer. Always ensure that you are following the most current safety guidelines and regulations.

Conclusion

Your safety is paramount. By following these instructions and guidelines, you can ensure the safe use of the EJECTOR SPRING with your Savage Arms firearm. Thank you for your attention to safety and for choosing our product.

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk