

# BERETTA SL3 12 GAUGE SAFETY SPRING - BERETTA USA BERETTA SL3 12 GAUGE SAFETY SPRING

[Shotgun Parts](#) > [Receiver & Action Parts](#) > [Safety Parts](#) > [Safety Springs](#)

BERETTA SL3 12 GAUGE SAFETY SPRING

NO IMAGE  
AVAILABLE

## Attributes

- Name: [BERETTA USA BERETTA SL3 12 GAUGE SAFETY SPRING](#)
- Manufacturer: [BERETTA USA](#)
- Product no.: 913500511
- Mfr. No.: C5G150
- Model: SL3
- Weapon type: Beretta
- Delivery weight: 0.045kg
- Shipping height: 3mm
- Shipping width: 89mm
- Shipping length: 152mm

# Table of Contents

- [Startpage](#)
- [BERETTA SL3 12 GAUGE SAFETY SPRING Safety Instruction Guide](#)
- [About Us](#)

# BERETTA SL3 12 GAUGE SAFETY SPRING Safety Instruction Guide

## Introduction

Thank you for choosing the BERETTA SL3 12 GAUGE SAFETY SPRING. This guide provides essential safety instructions to ensure the safe use and handling of your product. Please read this document carefully to understand how to use the safety spring safely and effectively.

## General Safety Guidelines

- Always handle the safety spring with care to prevent accidental injuries.
- Ensure that the safety spring is properly installed before use.
- Regularly inspect the safety spring for signs of wear or damage.
- Keep the safety spring out of reach of children and vulnerable individuals.
- Follow all local laws and regulations regarding firearm safety and usage.
- In case of any malfunction, stop using the product immediately and seek professional assistance.

## Specific Safety Precautions for Use

### • Installation Precautions:

- Ensure that the firearm is unloaded before installing or replacing the safety spring.
- Use appropriate tools to avoid damaging the safety spring during installation.

### • Usage Precautions:

- Always check that the safety mechanism is functioning correctly before using the firearm.
- Do not attempt to modify the safety spring or its installation.
- Never rely solely on the safety spring; always follow safe firearm handling practices.

### • Inspection Precautions:

- Regularly inspect the safety spring for any signs of wear, such as cracks or deformities.
- If any issues are detected, discontinue use and replace the safety spring immediately.

## Instructions for Installation and Usage

### 1. Installation:

- Ensure the firearm is completely unloaded.
- Remove the existing safety spring if applicable, using the appropriate tools.
- Align the new BERETTA SL3 12 GAUGE SAFETY SPRING in the designated slot.
- Secure the safety spring in place, ensuring it is fitted correctly and operates smoothly.

### 2. Usage:

- Before each use, confirm that the safety spring is functioning properly.
- Always engage the safety mechanism when the firearm is not in use.
- Follow the manufacturer's instructions for the specific firearm model to ensure proper usage.

### 3. Maintenance:

- Clean the safety spring regularly to remove any debris or residue.
- Store the firearm in a secure location when not in use, ensuring the safety spring is engaged.

## **Disposal Instructions**

- Dispose of any damaged or worn safety springs in accordance with local regulations.
- Do not dispose of safety springs in regular household waste. Instead, contact local waste management authorities for proper disposal methods.

## **Contact Information for Further Support**

For any questions or concerns regarding the BERETTA SL3 12 GAUGE SAFETY SPRING, please contact your local authorized dealer or refer to the manufacturer's website for additional support and resources.

By following these safety instructions, you can ensure the safe and effective use of your BERETTA SL3 12 GAUGE SAFETY SPRING. Thank you for prioritizing safety in your firearm handling practices.

# About Us

## Brownells UK

### **Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories**

Unit 1, Laughing Dog Industrial Estate  
London Road  
Rugby  
Warwickshire  
CV23 9LP

[www.brownells.co.uk](http://www.brownells.co.uk)