

RIFLE REAR SIGHT BLADE .250" U NOTCH BLACK

[Rifle Parts](#) > [Sights](#) > [Sight Parts](#) > [Rear Sight Blades](#)

Precision-made sight blades milled from high-tensile strength, rustproof alloy. Dovetailed windage and elevation adjustments have hardened gib locks. Make adjustments quickly by loosening one screw. No dovetailing of barrel necessary. Blades sold separately. Blades can also replace the aperture on WGRS sights.

NO IMAGE
AVAILABLE

Attributes

- Name: [RIFLE REAR SIGHT BLADE .250" U NOTCH BLACK](#)
- Manufacturer: [WILLIAMS GUN SIGHT](#)
- Product no.: 962350225
- Mfr. No.: 001578
- Color: Black
- Height: .250
- Make: Universal Rifles
- Style: U-Notch
- Delivery weight: 0.005kg
- Shipping width: 83mm
- Shipping length: 146mm
- UPC: 053506015788

Item details

Made in USA

Table of Contents

- Startpage
- RIFLE REAR SIGHT BLADE SAFETY INSTRUCTIONS
- About Us

RIFLE REAR SIGHT BLADE SAFETY INSTRUCTIONS

Introduction

Thank you for choosing the RIFLE REAR SIGHT BLADE. This guide provides essential safety instructions and guidelines to ensure the safe use of your product. It is important to read and understand these instructions carefully.

General Safety Guidelines

- Ensure that the sight blade is compatible with your rifle model before installation.
- Always handle firearms with care and follow standard firearm safety practices.
- Keep the sight blade out of reach of children and unauthorized users.
- Inspect the sight blade for any signs of damage or wear before each use.
- Report any accidents or unsafe products to the relevant authorities.

Specific Safety Precautions for Use

- Use only as intended: This sight blade is designed for use on universal rifles. Do not attempt to use it on other types of firearms.
- Avoid modifications: Do not alter the sight blade or its components in any way, as this may compromise safety.
- Wear appropriate eye protection: Always wear safety glasses when installing or adjusting the sight blade.
- Be cautious with adjustments: Make adjustments only when the firearm is unloaded and pointed in a safe direction.
- Follow the manufacturer's instructions for adjustments to avoid unintended movement or misalignment.

Instructions for Installation and Usage

1. Preparation:

- Ensure the firearm is unloaded.
- Gather necessary tools, including a screwdriver for adjustments.

2. Installation:

- Locate the dovetail slot on your rifle where the sight blade will be installed.
- Align the sight blade with the dovetail slot.
- Gently tap the sight blade into the slot until it is securely in place.
- Use a screwdriver to tighten the locking screws, ensuring the sight blade is stable.

3. Adjustments:

- To adjust the windage and elevation, loosen the appropriate screw using a screwdriver.
- Make small adjustments to achieve the desired alignment.
- Once adjustments are made, retighten the screws to secure the sight blade.

4. Post-Installation Check:

- After installation, check for stability and ensure that there is no movement in the sight blade.
- Test the sight alignment with your firearm at a safe location.

Disposal Instructions

- Dispose of any damaged or worn sight blades responsibly.
- Follow local regulations for the disposal of metal products.
- Do not dispose of the sight blade in household waste.

Contact Information for Further Support

For any inquiries regarding safety or product information, please contact the manufacturer or your local retailer. Ensure you have the product details ready for a more efficient response.

Thank you for prioritizing safety while using the RIFLE REAR SIGHT BLADE. Your adherence to these guidelines will help ensure a safe and enjoyable experience.

About Us

Brownells Austria

Brownells - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

www.brownells.at