

1911 AUTO "FACTORY PLUS" FIRING PINS - WILSON COMBAT FIRING PIN, 45ACP SERIES 70 OR 80

[Handgun Parts](#) > [Action Parts](#) > [Firing Pin Parts](#) > [Firing Pins](#)

Quality Parts Meet Or Exceed Factory Specs

1911 AUTO "FACTORY PLUS" FIRING PINS

Firing Pin, 45ACP Series 70 or 80



Attributes

- Name: [WILSON COMBAT FIRING PIN, 45ACP SERIES 70 OR 80](#)
- Manufacturer: [WILSON COMBAT](#)
- Product no.: 965011104
- Mfr. No.: R10,45
- Caliber: 45 Caliber (.451-.454)
- Model: Government,Commander,Officers
- Weapon type: 1911
- Delivery weight: 0.005kg
- Shipping width: 83mm
- Shipping length: 146mm
- UPC: 874218002916

Item details

Made in USA

US export classification: 0A501.x

Table of Contents

- [Startpage](#)
- [Safety Instructions for 1911 AUTO "FACTORY PLUS" FIRING PINS](#)
- [About Us](#)

Safety Instructions for 1911 AUTO "FACTORY PLUS" FIRING PINS

Introduction

Thank you for choosing the 1911 AUTO "FACTORY PLUS" FIRING PINS by Wilson Combat. This guide provides essential safety instructions to ensure the safe and effective use of your firing pins. It is important to read and understand this guide before using the product.

General Safety Guidelines

- Ensure that you are familiar with the operation and handling of firearms before using this product.
- Always treat every firearm as if it is loaded.
- Keep firearms out of reach of children and unauthorized users.
- Use appropriate eye and ear protection when handling or firing firearms.
- Regularly inspect your firearm and its components for wear and damage.
- Follow all local laws and regulations regarding firearm ownership and usage.

Specific Safety Precautions for Use

- Use only in firearms that are compatible with 45ACP Series 70 or 80 specifications.
- Ensure that the firearm is unloaded before installing or replacing firing pins.
- Do not modify the firing pins or any other firearm components.
- Always follow the manufacturer's instructions for installation and usage.
- If you experience any malfunctions or issues, cease use immediately and consult a qualified gunsmith.

Instructions for Installation and Usage

1. Preparation:

- Ensure the firearm is completely unloaded and stored in a safe location.
- Gather necessary tools, including a punch tool and a hammer if required.

2. Installation:

- Remove the slide from the firearm according to the manufacturer's instructions.
- Locate the firing pin retaining plate and remove it carefully.
- Remove the old firing pin from the channel.
- Insert the new 1911 AUTO "FACTORY PLUS" FIRING PIN into the firing pin channel.
- Replace the firing pin retaining plate, ensuring it is secure.

3. Usage:

- After installation, reassemble the firearm following the manufacturer's guidelines.
- Perform a function check to ensure the firing pin operates correctly.
- Store the firearm in a secure location when not in use.

Disposal Instructions

- Dispose of any damaged or worn firing pins according to local regulations regarding hazardous materials.
- Do not discard firing pins in regular household waste.
- Contact your local waste management authority for guidance on proper disposal methods.

Contact Information for Further Support

For any questions or concerns regarding the 1911 AUTO "FACTORY PLUS" FIRING PINS, please refer to the manufacturer's website or customer service for assistance.

Conclusion

By following these safety instructions, you can ensure the safe use of your 1911 AUTO "FACTORY PLUS" FIRING PINS. Always prioritize safety and consult professionals when in doubt. Thank you for your commitment to responsible firearm ownership.

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk