

DeadShot Shooting Bags - Deadshot Front Bag - Filled

[Shooting Accessories](#) > [Shooting Rests](#) > [Rifle Rests](#)

Every hunter and shooter is looking for a versatile and steady shooting system that can be set up almost anywhere, and at any time. Whether you have minutes or seconds to set up for your next shot, the DeadShot® Shooting Bags are the answer. These inexpensive and functional bags continue to set the industry standard for quality and functional shooting bags.

NO IMAGE
AVAILABLE

Attributes

- Name: [Deadshot Front Bag - Filled](#)
- Manufacturer: [Caldwell](#)
- Product no.: EU1001866
- Mfr. No.: 516620
- Delivery weight: 3.81kg
- Shipping height: 211mm
- Shipping width: 163mm
- Shipping length: 254mm
- UPC: 661120006572

Table of Contents

- Startpage
- Caldwell DeadShot Shooting Bags Safety Instructions
- About Us

Caldwell DeadShot Shooting Bags Safety Instructions

Introduction

Thank you for choosing the Caldwell DeadShot Shooting Bags. These bags are designed to provide a stable shooting platform for hunters and shooters, ensuring versatility and ease of use. This guide provides essential safety instructions to ensure your safe and effective use of the product.

General Safety Guidelines

- Ensure that the shooting bags are used only for their intended purpose.
- Always inspect the bags before use for any signs of damage or wear.
- Keep the bags out of reach of children when not in use.
- Use the bags in a safe shooting environment, away from bystanders and potential hazards.
- Be aware of your surroundings and ensure that no unauthorized persons are nearby while shooting.

Specific Safety Precautions for Use

- Do not exceed the recommended weight limit of the bags.
- Avoid using the bags on unstable or uneven surfaces.
- Always ensure that your firearm is pointed in a safe direction when adjusting your position with the bags.
- Use eye and ear protection while shooting.
- If the bags become wet, allow them to dry completely before use to prevent slipping.

Instructions for Installation and Usage

1. Setup:

- Place the front bag on a stable surface where you intend to shoot.
- Ensure that the bag is positioned securely and will not move during use.

2. Loading the Firearm:

- Place your firearm on top of the front bag, ensuring it is stable and secure.
- Adjust the position of the firearm as needed for comfort and accuracy.

3. Shooting:

- Take your shooting position, ensuring that your body is aligned with the target.
- Use the bag to support the front of the firearm, allowing for improved stability.
- Maintain proper shooting posture and focus on your target.

4. PostShooting:

- Once you have completed shooting, carefully remove the firearm from the bag.
- Store the shooting bags in a dry, safe place when not in use.

Disposal Instructions

- Dispose of the shooting bags in accordance with local regulations.
- Avoid burning the bags, as they may contain materials that can release harmful substances when incinerated.

- If the bags are damaged beyond repair, consider recycling the materials if possible.

Contact Information for Further Support

For any inquiries or safety concerns regarding the Caldwell DeadShot Shooting Bags, please refer to the product packaging for the appropriate contact details. Always ensure you have the latest information regarding safety recalls and updates.

Thank you for using the Caldwell DeadShot Shooting Bags. Your safety is our priority. Enjoy your shooting experience!

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk