

SEATERHEADS - TRIEBEL Seaterhead - Caliber 5,6/.223 - Type: R103

[Reloading](#) > [Reloading Dies](#) > [Neck Size Bushings](#)

Accessory for Seater with Crimp and Bench-Rest-Seaters from Triebel.

You will find further informations in the manual.

[The manual can be found here](#)

NO IMAGE
AVAILABLE

Attributes

- Name: [TRIEBEL Seaterhead - Caliber 5,6/.223 - Type: R103](#)
- Manufacturer: [TRIEBEL](#)
- Product no.: EU2008263
- Mfr. No.: 3000062
- Diameter (in): 0.223
- Delivery weight: 0.015kg
- Shipping height: 15mm
- Shipping width: 15mm
- Shipping length: 30mm

Table of Contents

- Startpage
- TRIEBEL Seaterhead Safety Instruction Guide
- About Us

TRIEBEL Seaterhead Safety Instruction Guide

Introduction

Thank you for choosing the TRIEBEL Seaterhead Caliber 5,6/.223 Type: R103. This product is designed to enhance your reloading experience while ensuring safety during use. It is essential to read and understand these safety instructions to prevent accidents and ensure proper handling of the product.

General Safety Guidelines

- Ensure that you are familiar with the operation and handling of reloading equipment before using this product.
- Always wear appropriate personal protective equipment (PPE), including safety glasses and gloves, when using reloading tools.
- Keep the product out of reach of children and unauthorized individuals.
- Regularly inspect the product for signs of wear or damage. Do not use if any components are damaged.
- Report any unsafe conditions or accidents to the appropriate authorities.
- Stay informed about product recalls and safety alerts through the EU Safety Gate platform.

Specific Safety Precautions for Use

- Only use the TRIEBEL Seaterhead with compatible crimp and benchrest seaters from Triebel.
- Ensure that the diameter of the Seaterhead matches the specifications of your reloading setup (0.223 inches).
- Avoid overtightening the Seaterhead when installing it on your reloading equipment, as this may cause damage.
- Do not modify the Seaterhead or use it for purposes other than intended.
- Always follow the manufacturer's instructions for the specific reloading equipment you are using in conjunction with the Seaterhead.

Instructions for Installation and Usage

1. Installation:

- Ensure that your reloading press is turned off and unplugged.
- Select the appropriate Seaterhead for your caliber (Caliber 5,6/.223).
- Carefully screw the Seaterhead into the designated holder on your reloading press until it is snug, but do not overtighten.
- Doublecheck that the Seaterhead is securely attached before proceeding.

2. Usage:

- Prepare your reloading components (cases, bullets, powder) according to your reloading manual.
- Set the desired seating depth according to your specifications.
- Place a case into the press and activate the press to seat the bullet using the Seaterhead.
- Monitor the seating process closely to ensure proper alignment and depth.
- After use, clean the Seaterhead and surrounding area to remove any debris or powder residue.

Disposal Instructions

- Dispose of the product in accordance with local regulations regarding electronic waste and reloading components.
- Do not dispose of the product in regular household waste.
- If the product is damaged beyond repair, contact your local waste disposal authority for guidance on

proper disposal methods.

Contact Information for Further Support

For any questions or concerns regarding the TRIEBEL Seaterhead or its safe usage, please refer to the manufacturer's manual or contact your local distributor for assistance.

By following these safety instructions, you can ensure a safe and effective reloading experience with your TRIEBEL Seaterhead. Thank you for your attention to safety!

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk