

SEATERHEADS - TRIEBEL Seaterhead - Caliber 6,7/.270 - Type: R80

[Reloading](#) > [Reloading Dies](#) > [Neck Size Bushings](#)

Accessory for Seater with Crimp and Bench-Rest-Seaters from Triebel.

You will find further informations in the manual.

[The manual can be found here](#)

NO IMAGE
AVAILABLE

Attributes

- Name: [TRIEBEL Seaterhead - Caliber 6,7/.270 - Type: R80](#)
- Manufacturer: [TRIEBEL](#)
- Product no.: EU2008298
- Mfr. No.: 3000100
- Diameter (in): 0.270
- Delivery weight: 0.015kg
- Shipping height: 15mm
- Shipping width: 15mm
- Shipping length: 30mm

Table of Contents

- [Startpage](#)
- [Safety Instruction Guide for TRIEBEL SEATERHEADS TRIEBEL Seaterhead Caliber 6,7/.270 Type: R80](#)
- [About Us](#)

Safety Instruction Guide for TRIEBEL SEATERHEADS TRIEBEL Seaterhead Caliber 6,7/.270 Type: R80

Introduction

Thank you for choosing the TRIEBEL Seaterhead. This product is designed to enhance your reloading experience with safety and precision. It is important to follow the safety instructions outlined in this guide to ensure safe operation and compliance with EU regulations.

General Safety Guidelines

- Always use the product in accordance with the manufacturer's instructions.
- Ensure that the product is suitable for the specific caliber and application.
- Regularly inspect the product for any signs of wear or damage.
- Keep the product out of reach of children and vulnerable individuals.
- Report any unsafe products or accidents to the relevant authorities.
- Stay informed about product recalls and safety updates via the EU's Safety Gate platform.

Specific Safety Precautions for Use

- Ensure that the Seaterhead is securely attached to the reloading press before use.
- Avoid using the Seaterhead if it appears damaged or malfunctioning.
- Use protective eyewear when operating the reloading press to prevent injury.
- Do not exceed the recommended load specifications for your reloading equipment.
- Handle all components with care to avoid accidental injury.

Instructions for Installation and Usage

1. Installation:

- Ensure the reloading press is turned off and unplugged.
- Attach the TRIEBEL Seaterhead to the reloading press according to the manufacturer's instructions.
- Confirm that the Seaterhead is securely fastened before proceeding.

2. Usage:

- Select the appropriate caliber and ensure compatibility with the Seaterhead.
- Prepare your reloading components according to standard reloading practices.
- Carefully follow the reloading procedure, ensuring that the Seaterhead operates smoothly.
- After use, clean the Seaterhead to maintain its performance and longevity.

Disposal Instructions

- Dispose of the product in accordance with local regulations for hazardous waste.
- Do not dispose of the product in regular household waste.
- Contact local waste management authorities for guidance on proper disposal methods.

Contact Information for Further Support

For any inquiries related to safety or product support, please refer to the manufacturer's contact details

provided in the product manual.

By adhering to these safety instructions, you can ensure a safe and effective experience with your TRIEBEL Seaterhead. Thank you for prioritizing safety in your reloading practices.

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk