

SEATERHEADS - TRIEBEL Seaterhead - Caliber 6,0/.243 - Type: R35

[Reloading](#) > [Reloading Dies](#) > [Neck Size Bushings](#)

Accessory for Seater with Crimp and Bench-Rest-Seaters from Triebel.

You will find further informations in the manual.

[The manual can be found here](#)

NO IMAGE
AVAILABLE

Attributes

- Name: [TRIEBEL Seaterhead - Caliber 6,0/.243 - Type: R35](#)
- Manufacturer: [TRIEBEL](#)
- Product no.: EU2008300
- Mfr. No.: 3000078
- Diameter (in): 0.243
- Delivery weight: 0.015kg
- Shipping height: 15mm
- Shipping width: 15mm
- Shipping length: 30mm

Table of Contents

- Startpage
- Safety Instruction Guide for TRIEBEL Seaterhead Caliber 6,0/.243 Type: R35
- About Us

Safety Instruction Guide for TRIEBEL Seaterhead

Caliber 6,0/.243 Type: R35

Introduction

Thank you for choosing the TRIEBEL Seaterhead. This product is designed to enhance your reloading experience with precision and safety. This guide provides essential safety instructions to ensure safe and effective use of the TRIEBEL Seaterhead.

General Safety Guidelines

- Always read and follow the manufacturer's instructions before using the product.
- Ensure that the product is used in a wellventilated area.
- Keep the product out of reach of children and vulnerable individuals.
- Regularly inspect the product for any signs of wear or damage before use.
- Report any unsafe products or accidents to the relevant authorities.
- Stay informed about recall updates on the EU's Safety Gate platform.

Specific Safety Precautions for Use

- Ensure that the Seaterhead is compatible with your reloading equipment.
- Use appropriate personal protective equipment (PPE), such as safety glasses and gloves.
- Do not exceed the recommended caliber specifications when using the Seaterhead.
- Avoid using the product if you are tired, distracted, or under the influence of substances that may impair your judgment.
- Always follow proper handling and storage procedures for ammunition components.

Instructions for Installation and Usage

1. Installation

- Ensure that your reloading press is turned off and unplugged before installation.
- Remove any existing Seaterhead from your reloading press.
- Carefully attach the TRIEBEL Seaterhead to the press, ensuring it is securely fastened.
- Refer to the manual for specific installation instructions and torque specifications.

2. Usage

- Before starting, check that all components are clean and free from debris.
- Set the desired depth of the bullet seating according to your reloading specifications.
- Place a cartridge case into the reloading press and ensure it is properly aligned.
- Slowly operate the press to seat the bullet, applying consistent pressure.
- After use, clean the Seaterhead and reloading press to maintain performance.

Disposal Instructions

- Dispose of the product in accordance with local regulations.
- Do not dispose of the product in regular household waste.
- If the product is damaged or no longer usable, consider recycling options where available.

Contact Information for Further Support

For any inquiries regarding the TRIEBEL Seaterhead, please refer to the manufacturer's contact details provided in the product manual. Ensure you have the product model and any relevant information ready for a quicker response.

Thank you for prioritizing safety and compliance while using the TRIEBEL Seaterhead. Enjoy your reloading experience!

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk