

SEATERHEADS - TRIEBEL Seaterhead - Caliber 6,0/.243 - Type: R42

[Reloading](#) > [Reloading Dies](#) > [Neck Size Bushings](#)

Accessory for Seater with Crimp and Bench-Rest-Seaters from Triebel.

You will find further informations in the manual.

[The manual can be found here](#)

NO IMAGE
AVAILABLE

Attributes

- Name: [TRIEBEL Seaterhead - Caliber 6,0/.243 - Type: R42](#)
- Manufacturer: [TRIEBEL](#)
- Product no.: EU2008301
- Mfr. No.: 3000073
- Diameter (in): 0.243
- Delivery weight: 0.015kg
- Shipping height: 15mm
- Shipping width: 15mm
- Shipping length: 30mm

Table of Contents

- [Startpage](#)
- [TRIEBEL Seaterhead Safety Instruction Guide](#)
- [About Us](#)

TRIEBEL Seaterhead Safety Instruction Guide

Introduction

Thank you for choosing the TRIEBEL Seaterhead Caliber 6,0/.243 Type: R42. This product is designed to enhance your reloading experience with precision and safety in mind. Please read this safety instruction guide carefully to ensure safe usage and compliance with the EU General Product Safety Regulation (GPSR).

General Safety Guidelines

- Ensure that the product is used only for its intended purpose.
- Always handle the Seaterhead with care to prevent injury.
- Keep the product out of reach of children and vulnerable individuals.
- Regularly inspect the Seaterhead for any signs of wear or damage before use.
- If you notice any issues, discontinue use immediately and seek assistance.

Specific Safety Precautions for Use

- Always wear appropriate safety gear, including eye protection, when using the Seaterhead.
- Do not exceed the recommended specifications for the caliber and type.
- Ensure that the Seaterhead is securely attached to the reloading press before use.
- Avoid using excessive force when operating the Seaterhead to prevent damage.
- Follow all manufacturer instructions and guidelines for the specific reloading equipment you are using.

Instructions for Installation and Usage

1. Installation:

- Ensure the reloading press is turned off and unplugged before installation.
- Carefully remove the Seaterhead from its packaging.
- Align the Seaterhead with the reloading press according to the manufacturer's instructions.
- Securely fasten the Seaterhead to the press to ensure stability during use.

2. Usage:

- Before starting, check that all components are properly installed and secure.
- Load the appropriate caliber (.243) and ensure all materials used are compatible.
- Operate the reloading press slowly and steadily to maintain control.
- After use, clean the Seaterhead according to the maintenance guidelines in the manual.

Disposal Instructions

- Dispose of any packaging materials in accordance with local recycling guidelines.
- If the Seaterhead is no longer usable, dispose of it as per local waste disposal regulations.
- Do not dispose of the product in regular household waste if it contains hazardous materials.

Contact Information for Further Support

For any questions or concerns regarding the TRIEBEL Seaterhead, please refer to the manual for further information. It is important to have access to the manual for troubleshooting and additional guidance.

Conclusion

By following the safety instructions outlined in this guide, you can ensure a safe and effective experience with your TRIEBEL Seaterhead. Always prioritize safety and refer to the manual for further information on usage and maintenance. Thank you for your commitment to safe reloading practices.

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk