

# SEATERHEADS - TRIEBEL Seaterhead - Caliber 6,0/.243 - Type: R45

[Reloading](#) > [Reloading Dies](#) > [Neck Size Bushings](#)

Accessory for Seater with Crimp and Bench-Rest-Seaters from Triebel.

**You will find further informations in the manual.**

[The manual can be found here](#)

NO IMAGE  
AVAILABLE

## Attributes

- Name: [TRIEBEL Seaterhead - Caliber 6,0/.243 - Type: R45](#)
- Manufacturer: [TRIEBEL](#)
- Product no.: EU2008302
- Mfr. No.: 3000077
- Diameter (in): 0.243
- Delivery weight: 0.015kg
- Shipping height: 15mm
- Shipping width: 15mm
- Shipping length: 30mm

# Table of Contents

- Startpage
- Safety Instruction Guide for TRIEBEL Seaterhead Caliber 6,0/.243 Type: R45
- About Us

# Safety Instruction Guide for TRIEBEL Seaterhead

## Caliber 6,0/.243 Type: R45

### Introduction

Thank you for choosing the TRIEBEL Seaterhead. This product is designed to enhance your reloading experience with precision and safety. Please read this safety instruction guide carefully to ensure the safe use of your Seaterhead and to understand how to operate it properly.

### General Safety Guidelines

- Ensure that the TRIEBEL Seaterhead is used only for its intended purpose as outlined in the manual.
- Always wear appropriate personal protective equipment (PPE) such as safety glasses when handling reloading equipment.
- Keep the Seaterhead and all reloading components out of reach of children and unauthorized users.
- Regularly inspect the Seaterhead for any signs of damage or wear before each use.
- In the event of a product recall, follow the instructions provided through official channels.

### Specific Safety Precautions for Use

- Always ensure the Seaterhead is securely attached to your reloading press before use.
- Do not exceed the recommended caliber specifications for the Seaterhead.
- Avoid using the Seaterhead in wet or damp conditions to prevent electrical hazards.
- Do not modify the Seaterhead or use it in any manner not specified in the manual.
- If you experience any difficulties during operation, cease use immediately and refer to the manual for troubleshooting.

### Instructions for Installation and Usage

#### 1. Installation:

- Ensure that your reloading press is clean and free from debris.
- Align the Seaterhead with the mounting points on your reloading press.
- Securely fasten the Seaterhead using the provided screws or clamps.
- Doublecheck that the Seaterhead is firmly attached before proceeding.

#### 2. Usage:

- Set up your reloading workspace in a wellventilated area.
- Prepare your components (cases, bullets, powder) as per your reloading recipe.
- Insert the case into the Seaterhead and ensure it is properly seated.
- Follow your specific reloading instructions for crimping and seating bullets.
- After use, clean the Seaterhead to remove any residue and maintain its functionality.

### Disposal Instructions

- Dispose of the TRIEBEL Seaterhead and any associated components in accordance with local waste disposal regulations.
- Do not dispose of the Seaterhead in regular household waste if it is damaged or no longer functional.
- Check with local authorities for proper disposal methods for metal and plastic components.

## **Contact Information for Further Support**

For any inquiries or further assistance regarding the TRIEBEL Seaterhead, please refer to the manual or contact the designated support channels. Always ensure you have the product information available when seeking assistance.

By following these safety instructions, you can ensure a safe and efficient reloading experience with your TRIEBEL Seaterhead. Thank you for your attention to safety and compliance with these guidelines.

# About Us

## Brownells UK

### **Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories**

Unit 1, Laughing Dog Industrial Estate  
London Road  
Rugby  
Warwickshire  
CV23 9LP

[www.brownells.co.uk](http://www.brownells.co.uk)